



XPress™ DR+ Industrial Device Server User Guide

Intellectual Property

© 2022 Lantronix, Inc. All rights reserved. No part of the contents of this publication may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

Lantronix is a registered trademark of Lantronix, Inc. in the United States and other countries. XPress and *DeviceInstaller* are trademarks of Lantronix, Inc.

Patented: patents.lantronix.com; additional patents pending.

Windows is a trademark of Microsoft Corporation. *Mozilla* and *Firefox* are registered trademarks of the Mozilla Foundation. All other trademarks and trade names are the property of their respective holders.

Warranty

For details on the Lantronix warranty policy, please go to our Web site at www.lantronix.com/support/warranty.

Contacts

Lantronix Corporate Headquarters

48 Discovery, Suite 250
Irvine, CA 92618, USA

Toll Free: 800-526-8766
Phone: 949-453-3990
Fax: 949-453-3995

Technical Support Online: www.lantronix.com/support

Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix web site at www.lantronix.com/about/contact.

Disclaimer & Revisions

Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his or her own expense, will be required to take whatever measures may be required to correct the interference.

Attention: *This product has been designed to comply with the limits for a Class A digital device pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against such interference when operating in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with this guide, may cause harmful interference to radio communications.*

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Changes or modifications to this device not explicitly approved by Lantronix will void the user's authority to operate this device.

The information in this guide may change without notice. The manufacturer assumes no responsibility for any errors that may appear in this guide.

Revision History

Date	Rev.	Comments
May 2016	A	Initial document for firmware version 6.11.0.2.
January 2017	B	Updated for firmware 6.11.0.4.
January 2018	C	Updated enhanced password information.
July 2022	D	Updated for firmware 7.0.0.1. Added new default password, label, and security information.

Table of Contents

List of Figures	7
List of Tables	8
1: Using This Guide	9
Purpose and Audience	9
Summary of Chapters	9
Additional Documentation	10
2: Introduction	11
Industrial Automation Protocols	12
Network Protocols (Serial Tunneling)	13
XPress DR+ Application Examples	14
Addresses and Port Numbers	15
Configuration Methods	16
3: Installation and Hardware	17
What's in the Box?	17
Connecting the XPress DR+ Device Server	17
XPress DR+ Front Panel	19
Serial Interface	19
Ethernet Interface	22
Power Requirements	23
Reset Switch	24
LEDs	25
Dimensions	26
Wall Mount Bracket	26
Product Information Label	27
4: Using DeviceInstaller	28
Installing DeviceInstaller	28
Assigning an IP Address	28
Accessing the XPress DR+ Using the DeviceInstaller Application	29
5: Configuration Using Web Manager	32
Accessing XPress DR+ Using DeviceInstaller	32
Network Configuration	34
Server Configuration	36
Host List Configuration	37

Channel Configuration _____	38
Applying Settings _____	46
Applying Factory Defaults _____	46
6: Configuration Using Telnet/Serial Port (Setup Mode)	47
Accessing Setup Mode _____	47
Exiting Setup Mode _____	49
7: Setup Mode: Server Configuration	50
Server Configuration (Option 0) _____	50
8: Setup Mode: Channel Configuration	53
Channel 1 (Option 1) and Channel 2 (Option 2) _____	53
Baudrate _____	53
Interface (I/F) Mode _____	54
Flow _____	55
Port Number _____	55
Connect Mode _____	56
Send the Escape Sequence (+++) in Modem Mode _____	62
Show IP Address After Ring _____	63
Auto Increment Source Port _____	63
Remote IP Address _____	63
Remote Port _____	63
DisConnMode _____	63
Flush Mode (Buffer Flushing) _____	64
Pack Control _____	65
DisConnTime (Inactivity Timeout) _____	66
Send Characters _____	66
Telnet Terminal Type _____	67
Channel (Port) Password _____	67
9: Setup Mode: Advanced Settings	68
Expert Settings (Option 5) _____	68
Security Settings (Option 6) _____	69
Default Settings (Option 7) _____	72
10: Firmware Upgrades	74
Obtaining Firmware _____	74
Reloading Firmware _____	74
11: Monitor Mode	77

12: Troubleshooting	80
Problems and Error Messages _____	80
DHCP _____	87
AutoIP _____	87
BOOTP _____	88
ARP and Telnet _____	88
Converting Binary to Hexadecimal _____	89
RoHS, REACH and WEEE Compliance Statement _____	92

List of Figures

Figure 2-1. XPress DR+ (Front)	12
Figure 2-2. Example of Serial Tunneling with Com Port Redirector	14
Figure 2-3. Example of Cascading Multiple XPress DR+ Units	15
Figure 3-1. Typical Configuration	18
Figure 3-2. Front of XPress DR+	19
Figure 3-3. RJ45 Connector – Front View	20
Figure 3-4. Screw Terminal Ports	21
Figure 3-5. Termination Resistor for 2-Wire Connection	21
Figure 3-6. Lantronix P/N 500-103-R RJ45-DB9F Serial Cable Pinout	22
Figure 3-7. Multi-Drop Ethernet Connections	23
Figure 3-8. Reset Switch	24
Figure 3-9. LEDs on the XPress DR+	25
Figure 3-10. Dimensions	26
Figure 3-11. Wall Mount Bracket	26
Figure 3-12. Product Label	27
Figure 5-1. Lantronix Web Manager	33
Figure 5-2. Network Settings	34
Figure 5-3. Server Settings	36
Figure 5-4. Hostlist Settings	38
Figure 5-5. Channel Serial Settings	39
Figure 5-6. TCP Connection Settings	42
Figure 5-7. UDP Connection Settings	45
Figure 5-8. Apply Settings	46
Figure 6-1. MAC Address	48
Figure 6-2. Setup Menu Options	48
Figure 8-1. Serial Port Parameters	53
Figure 8-2 Hostlist Option	59
Figure 9-1. Expert Settings	68
Figure 9-2. Security Settings	69
Figure 10-1. TFTP Window	75
Figure 11-1. Accessing Monitor Mode	77

List of Tables

Table 3-1. RJ45 Serial Connector Pinouts	20
Table 3-2. Serial Screw Terminal Pinout for RS-422 (4-Wire)	20
Table 3-3. Serial Screw Terminal Pinout for RS-485 (2-Wire)	20
Table 3-4. Ethernet Interface Signals	22
Table 3-5. Typical RJ45 Connector (View from Connector End)	23
Table 3-6. XPress DR+ LED Functions	25
Table 4-1. Viewing Current Settings	29
Table 7-1. BootP/DHCP/AutoIP options	50
Table 7-2. Standard IP Network Netmasks	51
Table 8-1. Interface Mode Options	54
Table 8-2. Common Interface Mode Settings	54
Table 8-3. Flow Control Options	55
Table 8-4. Reserved Port Numbers	55
Table 8-5 Connect Mode Options	56
Table 8-6 Manual Connection Address Example	58
Table 8-7 Modem Mode Messages	61
Table 8-8 Modem Mode Commands	62
Table 8-9 Disconnect Mode Options	64
Table 8-10 Flush Mode Options	64
Table 8-11 Pack Control Options	65
Table 10-1. Firmware Files	74
Table 11-1. Monitor Mode Commands	78
Table 11-2. Command Response Codes	79
Table 12-1. Problems and Error Messages	80

1: Using This Guide

Purpose and Audience

This user guide describes and provides the information needed to configure, use, and update the Lantronix® XPress™ DR+ industrial device server. These device servers are members of the XPress family that work with Industrial Automation Protocols (IAP). It is for system administrators and those responsible for installing and maintaining these device servers.

Summary of Chapters

The remaining chapters in this guide include:

Chapter	Description
2: Introduction	Describes the main features of the XPress DR+ and the protocols it supports.
3: Installation and Hardware	Describes the unit's interfaces and power requirements. Provides instructions for physically connecting the unit.
4: Using DeviceInstaller	Provides information for getting your unit up and running, using DeviceInstaller to assign an IP address.
5: Configuration Using Web Manager	Details using the Web Manager to set parameters such as port and server properties.
6: Configuration Using Telnet/Serial Port (Setup Mode)	Provides instructions for accessing Setup Mode (command line interface) using a Telnet connection through the network or a terminal or terminal emulation program through the serial port.
7: Setup Mode: Server Configuration	Details the network (server) settings.
8: Setup Mode: Channel Configuration	Details the serial port settings.
9: Setup Mode: Advanced Settings	Details email, expert, and security settings and explains how to reset the unit to factory default values.
10: Firmware Upgrades	Provides instructions for obtaining the latest firmware and updating the XPress DR+.
11: Monitor Mode	Provides instructions for accessing and using the command line interface for monitoring the network and diagnosing problems.
12: Troubleshooting	Describes common problems and error messages.
A: Technical Support	Provides information for obtaining Lantronix Technical Support.
B: Technical Specifications	Lists technical information about the unit.
C: Lantronix Cables and Adapters	Provides information on cables and adapters specific to the XPress DR+ industrial device server.
D: Alternative Methods of Assigning an IP Address	Describes other ways to assign an IP address, for example, though ARP and Telnet.

Chapter	Description
E: Binary and Hexadecimal Conversions	Provides instructions for converting binary numbers to hexadecimals.
F: Compliance Information	Provides the Declaration of Conformity and other regulatory information.

Additional Documentation

Visit the Lantronix Web site at www.lantronix.com/support/documentation for the latest documentation and the following additional documentation.

Document	Description
<i>XPress DR+ Industrial Device Server Quick Start Guide</i>	Provides the steps for getting the XPress DR+ up and running.
<i>Com Port Redirector Quick Start and Com Port Redirector Online Help</i>	Provides information on using the Windows®-based utility to create a virtual com port.
<i>DeviceInstaller Online Help</i>	Provides information on using the Lantronix DeviceInstaller™ application to locate Lantronix devices on the network and configure IP addresses.
<i>Live tutorials on the Lantronix Web Site</i>	Explain and demonstrate assigning an IP address and setting up the unit and the Redirector. See http://ltxfqa.custhelp.com/app/answers/detail/a_id/1119 . Note: The instructions for the UDS products apply to the XPress DR+ as well.
<i>Modbus Protocol User Guide</i>	Provides guides for the protocols, such as Modbus Bridge, which you can load on the XPress DR+ industrial device server.
<i>Com Port Redirector Quick Start and Com Port Redirector Online Help</i>	Provides information on using the Windows®-based utility to create a virtual com port.

2: Introduction

The Lantronix XPress DR+ industrial device server is a robust, feature-rich, and cost-effective way to network-enable equipment in an industrial automation environment. The XPress DR+ provides two serial ports, two switched Ethernet ports, a wide power input range, and expanded environmental specifications, making it an ideal solution for connecting multiple asynchronous RS-232, RS-422, or RS-485 serial devices to an Ethernet network.

The internal two-port Ethernet switch allows the XPress DR+ to cascade connections from a single network drop to another Ethernet device or from one XPress DR+ to another and another, and so on. By leveraging a single network drop to connect multiple devices, the XPress DR+ greatly reduces device connectivity costs, reduces cabling cost and simplifies system changes and device moves.

By encapsulating serial data and transporting it over Ethernet, the XPress DR+ allows virtual serial links over Ethernet and IP (TCP/IP, UDP/IP) networks. As a result, you can extend limited distance, point-to-point, direct serial connections within the plant, throughout the facility, or across the global enterprise.


The XPress DR+ provides an impressive list of features and functions enabling multiple industrial devices to be connected, controlled, configured, managed, and updated over a network. With two serial ports and two auto-sensing Ethernet ports, the XPress DR+ can easily connect multiple serial devices to a network and cascade from one XPress DR+ to another from a single network drop.

Types of supported devices:

- ◆ Programmable controllers (PLCs)
- ◆ Process controllers
- ◆ Motor drive controllers
- ◆ Power monitoring equipment
- ◆ Human-machine interfaces
- ◆ Robots
- ◆ Flow meters
- ◆ Temperature monitoring equipment
- ◆ Scales
- ◆ Mixing stations
- ◆ Gas detection devices
- ◆ CNC Machines

The XPress DR+ can connect devices using various methods of TCP/IP communications, for example, through a TCP data channel, using UDP datagrams, or through a Telnet connection. Communication can be established from the XPress DR+ to a host computer or another device or from a host computer or device to the XPress DR+.

Figure 2-1. XPress DR+ (Front)



The XPress DR+ supports RS-232 through RJ45 connectors. It also supports RS-422/485 by means of screw terminals (Serial Port 2 only). It has two Ethernet Ports 10/100Base-T and –TX with Auto MDI/MDI-X by means of RJ45 connectors. You can use either Ethernet port for daisy-chained configuration.

Industrial Automation Protocols

The XPress DR+, adapted to multiple factory environments, can unite any mixture of equipment from industrial automation vendors into a single reliable pipeline. This new and open infrastructure opens the way for data to flow in real time from all your plant devices up to your IT layer.

The XPress DR+ is delivered with IAP Standard Tunneling protocol and can be loaded with industrial communication protocols. The suite of protocols includes Modbus Bridge, which supports MODBUS/TCP, MODBUS/ASCII, and MODBUS/RTU (Schneider Electric). Where the IAP Standard Tunneling protocol is limited to standard ASCII device-to-device connections, the industrial protocols offer connections to other devices that require special formatting or features simultaneously.

For information about using any of the industrial communication protocols, find the protocol firmware files and the specific protocol guides at the Lantronix website at www.lantronix.com/support/downloads.html.

Note: Please check the Lantronix web site for newer versions that may become available.

You can set up the unit using serial port 1 or remotely over Ethernet using Telnet or, when using the standard tunneling firmware, a web browser. Download the Lantronix DeviceInstaller application at www.lantronix.com/support/downloads.html. The DeviceInstaller application is a Windows based configuration software that simplifies the process of installing protocols and configuring them for use with attached devices. The XPress DR+ uses Flash memory for maintenance-free, non-volatile storage that allows fast system upgrades.

Network Protocols (Serial Tunneling)

The XPress DR+ uses TCP/IP protocols for network communication. The supported standards are ARP, UDP, TCP, ICMP, Telnet, TFTP, DHCP, AutoIP, MODBUS/TCP, and SNMP. For transparent connections, TCP/IP (binary stream) or Telnet protocols are used. You can perform firmware upgrades with the TFTP protocol.

The Internet Protocol (IP) protocol defines addressing, routing, and data-block handling over the network. The TCP (transmission control protocol) assures that no data is lost or duplicated, and that everything sent into the connection on one side arrives at the target exactly as it was sent.

For typical datagram applications, where devices interact with others without maintaining a point-to-point connection, UDP datagram is supported in the Standard Tunnel Protocol.

XPress DR+ comes loaded with Standard Tunnel Protocol. Standard Tunneling is a serial communications protocol used by most Lantronix device servers. You can configure it to Ethernet-enable most serial devices such as barcode scanners, weigh scales, operator panels, data access devices, alphanumeric displays, and thousands of intelligent serial devices.


Loading industrial protocols such as Modbus Bridge to an XPress DR+ changes the configuration dialogs. See the user guides on individual protocols for protocol-specific settings and configuration dialogs.

Note: This user guide describes the setup and configuration dialogs for the Standard Tunnel Protocol.

XPress DR+ Application Examples


Using a method called serial tunneling, the XPress DR+ encapsulates serial data into packets and transports them over Ethernet. Using two XPress DR+ units, connected by a network, you can extend virtual serial connections across a facility or around the world.

Figure 2-2. Example of Serial Tunneling with Com Port Redirector



The internal two-port Ethernet switch allows the XPress DR+ to cascade connections from a single network drop to another Ethernet device or from one XPress DR+ to another and another, and so on.

Figure 2-3. Example of Cascading Multiple XPress DR+ Units



Addresses and Port Numbers

Hardware Address

The hardware address is also referred to as the Ethernet address or MAC address. Take note of the unit's hardware address (also known as the Ethernet or MAC address). It is on the product label (see [Product Information Label](#)).

Hardware Address: 00 – 20 – 4a – ____ – ____ – ____

OR

Hardware Address: 00 – 80 – A3 – ____ – ____ – ____

Note: Make note of the MAC address. It is needed to locate the XPress DR+ industrial device server using DeviceInstaller.

IP Address

Every device connected to an IP network must have a unique IP address. This address references the specific unit.

Port Numbers

Every TCP connection and every UDP datagram is defined by a destination IP address and a port number. For example, a Telnet application commonly uses port number 23. A port number is similar to an extension on a phone system.

You can associate the unit's serial channel (port) with a specific TCP/UDP port number. Port number 9999 is reserved for access to the unit's Setup (configuration) Mode.

Configuration Methods

After installation, the XPress DR+ requires configuration for the unit to operate correctly on a network. There are three basic methods for logging into the XPress DR+ and editing the configurable settings.

DeviceInstaller: Configures the IP address and other network settings on the XPress DR+ using a Graphical User Interface (GUI) on a PC attached to a network.
(See [4: Using DeviceInstaller](#).)

Web Manager: Through a web interface, configures the XPress DR+ settings using Web Manager. (See [5: Configuration Using Web Manager](#).)

Serial and Telnet Ports: There are two approaches to accessing Setup Mode: making a Telnet connection to the network port (9999) or connecting a terminal (or a PC running a terminal emulation program) to the unit's serial port.

3: Installation and Hardware

What's in the Box?

Verify and inspect the contents of the package using the enclosed packing slip or the list below. If any item is missing or damaged, contact your place of purchase immediately.

- ◆ XPress DR+ industrial device server
- ◆ XPress DR+ Industrial Device Server Quick Start Guide
- ◆ RJ45-DB9F serial cable (part number: 500-103-R)
- ◆ Accessory DIN-rail wall mount bracket
- ◆ 3-terminal screw connector for power input
- ◆ 5-terminal screw connector for serial port

What Must the User Provide?

- ◆ 9-30 VDC or 9-24 VAC power source
- ◆ CAT 5 Ethernet cable


Connecting the XPress DR+ Device Server

Note: To comply with the hazardous location approval of the XPress DR+, the unit must be installed in a tool-secured enclosure and wiring must be installed in accordance with Division 2 wiring practices as specified by the NEC.

This section describes the procedures for getting your unit up and running. For a short version, see the *XPress DR+ Industrial Device Server Quick Start Guide*. Detailed descriptions of the hardware components of the XPress DR+ follow this simple installation procedure.

The following diagram shows the basic connectivity of an XPress DR+ to the network and a serial device. The Lantronix-supplied part number 500-103-R serial cable can be used on the RJ45 RS-232 serial ports to connect the XPress DR+ to a PC or to a serial device that has a DB9M RS-232 DTE interface. If the device being connected uses a different serial interface, please refer to [Table 3-1. RJ45 Serial Connector Pinouts](#) for the serial interface pinout information or to [C: Lantronix Cables and Adapters](#) for a list of serial cables or adapters.

Figure 3-1. Typical Configuration




1. Connect a serial device to your XPress DR+. (See [Serial Interface](#) for cable and connector specifications.)
2. Connect an Ethernet cable to the Ethernet port. (See [Ethernet Interface](#).)
3. Supply power to your XPress DR+ using a 9-30 VDC or 9-24 VAC (2.3W maximum) source. (See [Power Requirements](#).)
4. Supply power to the serial device.

Note: Connecting a device to an active Ethernet network can disrupt communications on the network. Make sure the device is configured for your application before connecting it to an active network

XPress DR+ Front Panel

The following figure illustrates the screw terminal connector and other components of the XPress DR+.

Figure 3-2. Front of XPress DR+



Serial Interface


The XPress DR+ supports RS-232 via RJ45 connectors. It also supports RS-422/485 via screw terminals (Serial Port 2 only).

Note: Serial Port 2 supports RS-232, RS-422, and RS-485, but only one mode at a time. This means you can use either the RJ45 connector or the screw terminal, not both.

The RJ45 serial connectors only support RS-232, up to 230400 bits per second.

Table 3-1. RJ45 Serial Connector Pinouts

Pin	Direction	Name	Function
1	Output from DR+	RTS	Ready To Send
2	Output from DR+	DTR	Data Terminal Ready
3	Output from DR+	TXD	Transmitted Data
4	Ground	GND	Signal Ground
5	Ground	GND	Signal Ground
6	Input to DR+	RXD	Received Data
7	Input to DR+	DSR	Data Set Ready
8	Input to DR+	CTS	Clear To Send

Figure 3-3. RJ45 Connector – Front View

Screw Terminal Serial Connectors


Table 3-2. Serial Screw Terminal Pinout for RS-422 (4-Wire)

Pin	Direction	Name	Function
1	Output	TX+	Transmit Data +
2	Output	TX-	Transmit Data -
3	Ground	GND	Signal Ground
4	Input	RX+	Received Data +
5	Input	RX-	Received Data -

Table 3-3. Serial Screw Terminal Pinout for RS-485 (2-Wire)


Pin	Direction	Name	Function
1	Bi-directional	TX+/RX+	Transmit Data + and Received Data +
2	Bi-directional	TX-/RX-	Transmit Data – and Received Data -
3	Ground	GND	Signal Ground
4	Not Applicable	Not Applicable	Not Used
5	Not Applicable	Not Applicable	Not Used

Figure 3-4. Screw Terminal Ports



Note: Termination resistors ($R = 120\ \Omega$) are used to match impedance of a node to the impedance of the transmission (TX) line. Termination resistors should be placed only at the extreme ends of the data line, and no more than two terminations should be placed in any single segment of an RS-485 network. The termination resistors may not be needed for your application.


Figure 3-5. Termination Resistor for 2-Wire Connection



9-Pin RS-232 to Serial RJ45 Cable (P/N 500-103-R)

The included Lantronix (P/N 500-103) RJ45-DB9F serial cable assumes you are connecting a typical PC Com port to the XPress DR+ serial port. This cable is pinned to provide full serial line control to an RS-232 DTE device. Lantronix offers a comprehensive list of cables and adapters to simplify device connectivity to the XPress DR+ unit. See [C: Lantronix Cables and Adapters](#) for a full listing.

Figure 3-6. Lantronix P/N 500-103-R RJ45-DB9F Serial Cable Pinout



Ethernet Interface

The XPress DR+ includes a two-port unmanaged Ethernet switch with a future option to migrate to a managed solution.


The internal IEEE 802.3-compliant Ethernet switch is non-blocking, using a 1K MAC address lookup table with store-and-forward architecture. The XPress DR+ supports auto-negotiation for 10Base-T or 100Base-TX in full and half-duplex modes, as well as automatic MDI/MDIX crossover, allowing use of both straight-through and crossed Ethernet cables.

Table 3-4. Ethernet Interface Signals

Pin	Direction	Name	Function
TX+	Out	1	Transmit Data +
TX-	Out	2	Transmit Data -
RX+	In	3	Differential Ethernet Receive Data +
RX-	In	6	Differential Ethernet Receive Data -

The next drawing shows a typical RJ45 connector. The color is not standard but very typical of an Ethernet patch cable. Pin 1 is located at the top of the connector (orange + white). The view is from the end of the connector.


Table 3-5. Typical RJ45 Connector (View from Connector End)



Multi-Drop Ethernet Connections

Although there are two Ethernet ports, the XPress DR+ only has one MAC address and IP address. Either port can be used as the primary connection with the other used to inter-connect other Ethernet devices or cascade from one XPress DR+ to another.

Figure 3-7. Multi-Drop Ethernet Connections



Power Requirements

As with most industrial automation devices, the XPress DR+ does not ship with a power supply. Its flexible power input circuit allows the product to be powered by any 9-30 VDC or 9-24 VAC power supply with a Limited Power Source (LPS) which can provide the 2.3 Watt maximum required by the XPress DR+ industrial device server.


In addition to the wide power input range, the XPress DR+ provides:

- ◆ 2K VAC and 2.8K VDC galvanic isolation between the power input and the Ethernet ports
- ◆ 2K VAC and 2.8K VDC galvanic isolation between the power input and the serial ports

Reset Switch

The XPress DR+ includes a hardware reset switch located in the small hole above the power connector. Pressing the reset switch causes a hardware reboot of the XPress DR+. The hardware reset does not reset or change the configuration of the XPress DR+.

Figure 3-8. Reset Switch



Caution: Even though a chassis ground is not required for operation, it is mandatory for protection against transient voltages and ESD. A chassis ground must be connected to the ground.

LEDs

Figure 3-9. LEDs on the XPress DR+





Table 3-6. XPress DR+ LED Functions

LED	Status	Meaning
Serial port - TXD LED (Yellow)	Off	No data being transmitted from XPress DR+
	Blinking	Data being transmitted from XPress DR+
Serial port - RXD LED (Green)	Off	No data being received by XPress DR+
	Blinking	Data being received by XPress DR+
Ethernet port - 10/100 Link (Green)	Off	No Ethernet link established
	Steady On	Ethernet link established
Ethernet port – Activity (Yellow)	Off	No data activity
	Blinking	Data activity
Power/Diagnostic LED (Orange)	Steady On	Power OK
	Blinking 2x	No DHCP response
	Blinking	Setup Menu active

Dimensions

The following drawing shows the dimensions of the XPress DR+.


Figure 3-10. Dimensions



Wall Mount Bracket

Included with the XPress DR+ is an accessory DIN-rail wall mount bracket that makes it very easy to mount the unit in locations where a DIN-rail is not available.

Figure 3-11. Wall Mount Bracket



Product Information Label

The product information label on the underside of the unit contains important information about your specific unit:

- ◆ Product Part Number
- ◆ Product Revision
- ◆ Manufacturing Date Code
- ◆ Country of Manufacturing Origin
- ◆ Serial Number (which is also the product MAC address)
- ◆ QR Code

Your unit will have one *similar* to the one below.

Figure 3-12. Product Label



Note: Before mounting the device on a DIN-rail, copy the information from the label.

4: Using DeviceInstaller

This chapter covers the steps for getting the XPress DR+ device server online and viewing its current configuration.

Note: For the latest firmware, release notes, and user documentation, go to the Lantronix web site (www.lantronix.com/downloads).

Installing DeviceInstaller

1. Download the latest version of the Lantronix DeviceInstaller application from: www.lantronix.com/downloads.
2. Run the executable to start the installation process.
3. Respond to the installation wizard prompts. (If prompted to select an installation type, select **Typical**.)

Assigning an IP Address


The unit's IP address must be configured before it can work correctly on a network. You have several options for assigning an IP address to your unit. We recommend that you manually assign the IP address over the network using the DeviceInstaller utility.

Note: To use a serial connection instead of an Ethernet connection to configure the device, see [6: Configuration Using Telnet/Serial Port \(Setup Mode\)](#). The unit's IP address is normally set to 0.0.0.0 at the factory. The hardware (MAC) address is on the product label. The unit is DHCP-enabled as the default.

To assign an IP address manually:

1. Click **Start→Programs → Lantronix→DeviceInstaller 4.4 →DeviceInstaller**. If your PC has more than one network adapter, a message displays. Select an adapter and click **OK**.

Note: If the unit already has an IP address (e.g., DHCP has assigned an IP address), click the **Search** icon and select the unit from the list of Lantronix device servers on the local network.

2. Click the **Assign IP**  icon.
3. If prompted, enter the hardware address (on the product label) and click **Next**.
4. Select Assign a specific IP address and click **Next**.
5. Enter the **IP address**. The **Subnet mask** displays automatically based on the IP address; if desired, you may change it. On a local network, you can leave the **Default gateway** blank (all zeros). Click **Next**.

6. Click the **Assign** button and wait several seconds until a confirmation message displays. Click **Finish**.

7. Select the device from the main window list and select **Ping** from the **Tools** menu. The Ping Device dialog box shows the IP address of the selected unit.

8. Click the **Ping** button. The results display in the Status window. Click the **Clear Status** button to clear the window so you can ping the device again.

Note: If you do not receive “Reply” messages, make sure the unit is properly attached to the network and that the IP address assigned is valid for the particular network segment you are working with. If you are not sure, check with your systems administrator.

9. Click the **Close** button to close the dialog box and return to the main window.

Accessing the XPress DR+ Using the DeviceInstaller Application

Note: Make note of the MAC address. It may be needed to perform various functions in the DeviceInstaller application.

1. Click **Start > All Programs > Lantronix > DeviceInstaller 4.4 > DeviceInstaller**.

When DeviceInstaller starts, it will perform a network device search.

2. Click **Search** to perform additional searches, as desired.

3. Expand the **XPress** folder by clicking the **+** symbol next to the **XPress** folder icon. The list of available Lantronix XPress DR+ devices appear.

4. Select the XPress DR+ unit by expanding its entry and clicking on its hardware (MAC) or IP address to view its configuration.

5. On the right page, click the **Device Info** tab. The current XPress DR+ configuration appears. This is only a subset of the full configuration; the complete configuration may be accessed via Web Manager or the CLI.

Note: The settings are Display Only in this table unless otherwise noted.

Table 4-1. Viewing Current Settings

Setting	Description
Name	Configurable field. A name that identifies the XPress DR+. Double-click the field, type in the value, and press Enter to complete. This name is not visible on other PCs or laptops using DeviceInstaller.
DHCP Device Name	Shows the name associated with the current IP address, if the IP address was obtained dynamically.
Group	Configurable field. A group name to categorize the XPress DR+. Double-click the field, type in the value, and press Enter to complete. This group name is not visible on other PCs or laptops using DeviceInstaller.

Setting	Description
Comments	Configurable field. Information about the XPress DR+. Double-click the field, type in the value, and press Enter to complete. This description or comment is not visible on other PCs or laptops using DeviceInstaller.
Device Family	Non-configurable field. Displays the unit's device family type as XPress .
Type	Non-configurable field. Displays the device type as XPress DR+ .
ID	Non-configurable field. Displays the unit's ID embedded within the box.
Hardware Address	Non-configurable field. Displays the unit's hardware (or MAC) address.
Firmware Version	Non-configurable field. Displays the firmware currently installed on the XPress DR+.
Extended Firmware Version	Non-configurable field. Displays the full version nomenclature of the firmware.
Online Status	Non-configurable field. Displays the unit's status as online, offline, unreachable (the XPress DR+ is on a different subnet), or busy (the XPress DR+ is currently performing a task).
IP Address	Non-configurable field. Shows the XPress DR+ device's current IP address. To change the IP address, click the Assign IP button on the DeviceInstaller menu bar.
IP Address was Obtained	Displays "Dynamically" if the device automatically received an IP address (e.g., from DHCP). Displays "Statically" if the IP address was configured manually. If the IP address was assigned dynamically, the following fields appear: <ul style="list-style-type: none"> ♦ Obtain via DHCP with value of True or False. ♦ Obtain via BOOTP with value of True or False. ♦ Obtain via RARP with value of True or False ♦ Obtain via Auto IP with value of True or False
Subnet Mask	Shows the subnet mask specifying the network segment on which the XPress DR+ resides.
Gateway	Shows the IP address of the router of this network. There is no default.
Number of COB partitions supported	Non-configurable field. Displays the number of COB partitions supported.
Number of Serial Ports	Non-configurable field. Displays the number of serial ports on this XPress DR+ unit.
TCP Keepalive	Non-configurable field. Displays the unit's TCP keepalive value. The value is in the range 1-65s, and the default setting is 45 .
Telnet Supported	Non-configurable field. Displays True . Permits Telnet sessions.
Telnet Port	Non-configurable field. Displays the unit's port for telnet sessions.
Web Port	Non-configurable field. Displays the unit's port for Web Manager configuration.
Maximum Baud Rate Supported	Non-configurable field. Displays the unit's maximum baud rate. <i>Note: The XPress DR+ may not be running at this rate currently.</i>
Firmware Upgradeable	Non-configurable field. Displays True , indicating the unit's firmware is upgradeable as newer versions become available.
Supports Configurable Pins	Non-configurable field. Displays False , indicating configurable pins are not available on the XPress DR+.

Setting	Description
Supports Email Triggers	Non-configurable field. Displays False .
Supports AES Data Stream	Non-configurable field. Displays False .
Supports 485	Non-configurable field. Displays True . XPress DR+ supports the RS-485 protocol.
Supports 921K Baudrate	Non-configurable field. Displays False . XPress DR+ supports baud rates up to a maximum of 230 Kbaud.
Supports HTTP Server	Non-configurable field. Displays True .
Supports HTTP Setup	Non-configurable field. Displays True .
Supports 230K Baud Rate	Non-configurable field. XPress DR+ supports a baud rate of 230 Kbaud. Displays True .
Supports GPIO	Non-configurable field. Displays False .

5: Configuration Using Web Manager

You must configure the unit so that it can communicate on a network with your serial device. For example, you must set the way the unit will respond to serial and network traffic, how it will handle serial packets, and when to start or close a connection.

The unit's configuration is stored in nonvolatile memory and is retained without power. You can change the configuration at any time. The unit performs a reset after you change and store the configuration.


In this chapter, we describe how to configure the XPress DR+ using Web Manager, a Lantronix browser-based configuration tool. Web Manager refers to our web-based configuration manager for the device server product. (For information on using Setup Mode, our command line configuration interface, see [6: Configuration Using Telnet/Serial Port \(Setup Mode\)](#)).

Notes:

- ◆ *The examples in this section show a typical device. Your device may have different configuration options.*
- ◆ *For the latest firmware, release notes, and user documentation, go to the Lantronix web site (www.lantronix.com/downloads).*

Accessing XPress DR+ Using DeviceInstaller

Note: For more information on the DeviceInstaller application, see [4: Using DeviceInstaller](#).

1. Run the DeviceInstaller application and search for the list of available Lantronix device servers.
2. Click on the **XPress** folder. The list of available XPress DR+ units displays.
3. Expand the list of XPress DR+ devices by clicking the + symbol next to the XPress DR+ icon.
4. Select the XPress DR+ unit by clicking its hardware address.
5. In the right pane, click the **Web Configuration** tab.
6. To view the unit's Web Manager in the current DeviceInstaller window, click  button in the upper right corner of the DeviceInstaller window.

- OR -

To open the Web Manager in a web browser, click the **External Browser** button. The Web Manager displays.

Note: Alternatively, to open Web Manager, start your web browser and enter the IP address of the XPress DR+ device server.

A dialog box appears to prompt for a **User name** and **Password**.

7. Perform one of the following:

- a) If no Telnet/Web Manager password has been defined, leave both fields blank and click **OK**.
- b) If a Telnet/Web Manager password has been defined, leave the username blank, type in the password, and then click **OK**.

Note: We recommend that you always use the enhanced password setting and create a strong 16-character password. See [Security Settings \(Option 6\)](#) on page 68.

The Web-Manager displays.

Figure 5-1. Lantronix Web Manager

Device Status	
Product Information	
Firmware Version:	V6.11.0.4
Build Date:	16-Sep-2016
Network Settings	
MAC Address:	00-80-A3-8E-3C-7A
Network Mode:	Wired
DHCP HostName:	< None >
IP Address:	172.19.205.77
Default Gateway:	0.0.0.0
DNS Server:	0.0.0.0
MTU:	1400
Line settings	
Line 1:	RS232, 9600, 8, None, 1, None.
Line 2:	RS232, 9600, 8, None, 1, None.

The main menu is in the left pane of the Web Manager window.

Network Configuration

The unit's network values display when you select **Network** from the main menu. The following sections describe the configurable parameters on the Network Settings page.

Figure 5-2. Network Settings

Automatic IP Address Configuration

An IP address can be assigned automatically. You then enter related network settings.

To assign an IP address automatically:

1. On the main menu, click **Network**.
2. From the **Network Mode** drop-down list, **Wired Only** is preselected for wired configuration.
3. Select **Obtain IP address automatically**.
4. Enter the following (as necessary):

BOOTP	Select Enable to permit the Bootstrap Protocol (BOOTP) server to assign the IP address from a pool of addresses automatically. Enable is the default setting.
DHCP	Select Enable to permit the Dynamic Host Configuration Protocol (DHCP) to assign a leased IP address to the XPress DR+ unit automatically. Enable is the default setting.
AutoIP	Select Enable to permit the XPress DR+ to generate an IP in the 169.254.x.x address range with a Class B subnet. Enable is the default setting.

DHCP Host Name	Enter the name of the host on the network providing the IP address.
-----------------------	---

Note: *Disabling BOOTP, DHCP, and AutoIP (all three checkboxes) is not advised as the only available IP assignment method will then be ARP or the serial port.*

- When finished, click the **OK** button.
- To save and reboot, click **Apply Settings** on the main menu.

Static IP Address Configuration

You manually assign an IP address to the unit and enter related network settings.

To assign an IP address manually:

- On the main menu, click **Network**.
- From the **Network Mode** drop-down list, **Wired Only** is preselected for wired configuration.
- Select **Use the following IP configuration**.
- Enter the following (as necessary):

IP Address	Enter the IP address manually in decimal-dot notation. The IP address must be set to a unique value in the network.
Subnet Mask	A subnet mask defines the number of bits taken from the IP address that are assigned for the host part.
Default Gateway	The gateway address, or router, allows communication to other LAN segments. The gateway address should be the IP address of the router connected to the same LAN segment as the unit. The gateway address must be within the local network.
DNS Server	Enter the DNS Server. The DNS server allows the name of a remote machine to be resolved automatically. Enter the IP address of the DNS server. If the device is DHCP enabled, the DHCP server provides the DNS server IP address, which will override this configured value.

- When finished, click the **OK** button.
- To save and reboot, click **Apply Settings** on the main menu.

Server Configuration

The unit's server values display when you select **Server** from the main menu. The following sections describe the configurable parameters on the Server Settings page.

Figure 5-3. Server Settings

To configure the unit's device server settings:

1. On the main menu, click **Server**.
2. Configure or modify the following fields:

Server Configuration

Enhanced Password	<p>Select whether to enable enhanced password:</p> <ul style="list-style-type: none"> ♦ Enable: selecting this option enables advanced password creation, allowing you to create passwords up to 16 bytes in length. ♦ Disable: selecting this option disables advanced password creation, allowing you to create basic passwords up to 4 bytes in length. <p>Note: We recommend that you always enable the enhanced password setting and create a strong 16-character password. This is enabled by default on devices manufactured after January 1, 2020.</p>
Telnet/Web Manager Password	Enter the password required for Telnet configuration and Web Manager access.

Retype Password	Re-enter the password required for Telnet configuration and Web Manager access.
------------------------	---

Advanced

ARP Cache Timeout (secs)	When the unit communicates with another device on the network, it adds an entry into its ARP table. ARP Cache timeout defines the number of seconds (0-600) before it refreshes this table. 0 disables ARP Cache Timeout. The default setting is 600.
TCP Keepalive (secs)	Defines how many seconds the unit waits during an inactive connection before checking its status. If the unit does not receive a response, it drops that connection. Enter a value between 0 and 65 seconds. 0 disables keepalive. The default setting is 45 .
Monitor Mode @ Bootup	Select Disable to disable entry into the monitor mode using the yyy or xx1 key sequence at startup. This field prevents the unit from entering monitor mode by interpreting the stream of characters that are received during the device server's initialization at startup.
HTTP Server Port	This option allows the configuration of the web server port number. The valid range is 1-65535. The default setting is 80 .
Config Server Port	Not applicable for this product.
MTU Size	The Maximum Transmission Unit (MTU) is the largest physical packet size a network can transmit for TCP and UDP. Enter between 512 and 1400 bytes. The default setting is 1400 bytes.
TCP Re-transmission timeout (ms)	The desired TCP re-transmission timeout value. If the ACK is not received for a packet sent from the XPress DR+ device, then the unit will retransmit the data. The valid range is 500-4000 msec. Default is 500 msec.

- When you are finished, click the **OK** button.
- To save and reboot, on the main menu, click **Apply Settings**.

Host List Configuration

The XPress DR+ scrolls through the host list until it connects to a device listed in the host list table. After a successful connection, the unit stops trying to connect to any others. If this connection fails, the unit continues to scroll through the table until the next successful connection.

The host list supports a minimum of 1 and a maximum of 12 entries. Each entry contains an IP address and a port number.

Note: The host list is disabled for Manual and Modem Mode. The unit does not accept a data connection from a remote device when the host list option is enabled.

To configure the unit's host list:

- On the main menu, click **Hostlist**.

Figure 5-4. Hostlist Settings

XPress™ DR+ **LANTRONIX®**

Hostlist Settings

Retry Settings
 Retry Counter: Retry Timeout:

Host Information

No.	Host Address	Port	No.	Host Address	Port
1	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>	2	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>
3	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>	4	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>
5	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>	6	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>
7	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>	8	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>
9	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>	10	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>
11	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>	12	<input type="text" value="0.0.0.0"/>	<input type="text" value="0"/>

- Enter or modify the following fields:

Retry Settings

Retry Counter	Enter the value for the number of times the XPress DR+ should attempt to retry connecting to the host list. The default setting is 3 .
Retry Timeout	Enter the duration (in milliseconds) the XPress DR+ should abandon attempting a connection to the host list. The default setting is 250 .

Host Information

Host Address	Enter or modify the host's IP address.
Port	Enter the target port number.

- When finished, click the **OK** button.
- To save and reboot, click **Apply Settings** on the main menu.

Channel Configuration

The Channel 1 and Channel 2 configurations define how the serial ports respond to network and serial communication.

Note: Channel 1 and Channel 2 have the same defaults except for the port number (10001 for Channel 1 and 10002 for Channel 2). The procedures below are for Channel 1; they are the same for Channel 2.

Serial Settings

To configure the channel's serial settings:

1. On the main menu, click **Serial Settings** (below Channel 1) to display the Serial Settings window.

Figure 5-5. Channel Serial Settings

The screenshot shows the 'Serial Settings' window for 'Channel 1' in the XPress™ DR+ LANTRONIX® web manager. The left sidebar contains a navigation menu with options: Network, Server, Serial Tunnel, Hostlist, Channel 1 (selected), Serial Settings (highlighted), Connection, Channel 2, Serial Settings, Connection, Apply Settings, and Apply Defaults. The main content area is titled 'Serial Settings' and includes the following sections:

- Channel 1**: A checkbox for 'Disable Serial Port'.
- Port Settings**: Fields for Protocol (RS232), Baud Rate (9600), Data Bits (8), Flow Control (None), Parity (None), and Stop Bits (1).
- Pack Control**: A checkbox for 'Enable Packing', an 'Idle Gap Time' field (12 msec), 'Match 2 Byte Sequence' (Yes/No), 'Match Bytes' (0x00), 'Send Frame Immediate' (Yes/No), and 'Send Trailing Bytes' (None/One/Two).
- Flush Mode**: Two columns of settings for 'Flush Input Buffer' and 'Flush Output Buffer', each with 'With Active Connect', 'With Passive Connect', and 'At Time of Disconnect' (Yes/No).

An 'OK' button is located at the bottom right of the settings area.

2. In the available fields, enter the following information:

Channel 1

Disable Serial Port	When selected, disables communication through the serial port. The serial port is enabled by default. Note: Using a telnet session you may enter a baud rate of 00 in channel settings to disable the serial port.
----------------------------	--

Port Settings

Protocol	From the drop-down menu, select the protocol type for the selected channel. The default setting is RS232 . Note: Configuring RS-485 is permitted on Channel 2 and not permitted on Channel 1.
-----------------	--

Flow Control	Flow control manages data flow between devices in a network to ensure the data is processed efficiently. Too much data arriving before a device is prepared to manage it causes lost or retransmitted data. None is the default setting.
Baud Rate	The unit and attached serial device, such as a modem, must agree on a speed or baud rate to use for the serial connection. Valid baud rates are 300, 600, 1200, 2400, 4800, 9600 (default), 19200, 38400, 57600, 115200, or 230400.
Data Bits	Indicates the number of bits in a transmitted data package. The default setting is 8 .
Parity	Checks for the parity bit. The default setting is None .
Stop Bits	The stop bit follows the data and parity bits in serial communication. It indicates the end of transmission. The default setting is 1 .

Pack Control

Enable Packing	<p>Select to enable packing on the XPress DR+. Disabled by default.</p> <p>Two firmware-selectable packing algorithms define how and when packets are sent to the network.</p> <p>The standard algorithm is optimized for applications in which the unit is used in a local environment, allowing for very small delays for single characters, while keeping the packet count low.</p> <p>The alternate packing algorithm minimizes the packet count on the network and is especially useful in applications in a routed Wide Area Network (WAN). Adjusting parameters in this mode can economize the network data stream.</p>
Idle Gap Time	Select the maximum time for inactivity. The default time is 12 milliseconds.
Match 2 Byte Sequence	Use to indicate the end of a series of data to be sent as one group. The sequence must occur sequentially to indicate end of the data collection to the XPress DR+. The default setting is No .
Match Bytes	Use to indicate the end of a series of data to be sent as one group. Set this value to 00 if specific functions are not needed.
Send Frame Immediate	After the detection of the byte sequence, indicates whether to send the data frame or the entire buffer. Select Yes to send only the data frame. The default setting is No .
Send Trailing Bytes	Select the number of bytes to send after the end-of-sequence characters. The default setting is None .

Flush Input Buffer (Serial to Network)

With Active Connect	Select Yes to clear the input buffer with a connection that is initiated from the device to the network. The default setting is No .
With Passive Connect	Select Yes to clear the input buffer with a connection initiated from the network to the device. The default setting is No .
At Time of Disconnect	Select Yes to clear the input buffer when the network connection to or from the device is disconnected. The default setting is No .

Flush Output Buffer (Network to Serial)

With Active Connect	Select Yes to clear the output buffer with a connection that is initiated from the device to the network. The default setting is No .
With Passive Connect	Select Yes to clear the output buffer with a connection initiated from the network to the device. The default setting is No .
At Time of Disconnect	Select Yes to clear the output buffer when the network connection to or from the device is disconnected. The default setting is No .

3. When finished, click the **OK** button.
4. To save and reboot, click **Apply Settings** on the main menu.

Connection Settings - TCP

To configure a channel's TCP settings:

1. On the main menu, click **Connection**. The Connection Settings window for the channel displays.

Figure 5-6. TCP Connection Settings

The screenshot shows the 'Connection Settings' page for 'Channel 1' in the XPress DR+ LANTRONIX web interface. The left sidebar contains navigation links: Network, Server, Serial Tunnel, Hostlist, Channel 1, Serial Settings, Connection (highlighted), Channel 2, Serial Settings, Connection, Apply Settings, and Apply Defaults. The main content area is titled 'Channel 1' and contains the following settings:

- Connect Protocol:** Protocol: TCP (dropdown)
- Connect Mode:**
 - Passive Connection:**
 - Accept Incoming: Yes (dropdown)
 - Password Required: ☐ Yes ☒ No
 - Password: (text field)
 - Modem Escape Sequence Pass Through: ☒ Yes ☐ No
 - Active Connection:**
 - Active Connect: None (dropdown)
 - Start Character: 0x0D (in Hex)
 - Modem Mode: None (dropdown)
 - Show IP Address After RING: ☒ Yes ☐ No
- Endpoint Configuration:**
 - Local Port: 10001
 - Remote Port: 0
 - ☐ Auto increment Local Port for active connect
 - Remote Host: 0.0.0.0
- Common Options:**
 - Telnet Com Port Cntrl: Disable (dropdown)
 - Connect Response: None (dropdown)
 - Terminal Name: (text field)
 - Use Hostlist: ☐ Yes ☒ No
 - LED: Blink (dropdown)
- Disconnect Mode:**
 - On Mdm_Ctrl_In Drop: ☐ Yes ☒ No
 - Hard Disconnect: ☒ Yes ☐ No
 - Check EOT(Ctrl-D): ☐ Yes ☒ No
 - Inactivity Timeout: 0 : 0 (mins : secs)

An 'OK' button is located at the bottom right of the settings area.

- In the available fields, enter or modify the following information:

Connect Protocol

Protocol	From the drop-down menu, select TCP .
----------	--

Connect Mode: Passive Connection

Accept Incoming	Select Yes to accept incoming connections. The default setting is Yes .
Password Required	Determines whether a password is required for an incoming passive connection. This field is not available when a password is set for Telnet mode. The default setting is No .
Password	If Password Required was set to Yes , enter the password for passive connections.
Modem Escape Sequence Pass Through	Disable or enable the XPress DR+ ability to send the escape sequence. The default is Yes (send the escape sequence).

Connect Mode: Active Connection

Active Connect	Select None (default) to disable Active Connect . Otherwise, select the connection type from the drop-down list: <ul style="list-style-type: none"> ♦ With Any Character: Attempts to connect when any character is received from the serial port. ♦ With Active Mdm Ctrl In: Accepts external connection requests only when the modem_control_in input is asserted. ♦ With Start Character: Attempts to connect when it receives a specific start character from the serial port. The default start character is carriage return. ♦ Manual Connection: Attempts to connect when directed by a command string received from the serial port. ♦ Auto Start: Automatically connects to the remote IP address and port after booting up.
Start Character	If Active Connect is set to With Start Character , enter the start character in this field. The default setting is 0D .
Modem Mode	Indicates the on-screen response type when in Modem Mode (if Modem Mode is enabled). The default setting is None .
Show IP Address After RING	Indicates whether to display the remote IP address upon connection. The default setting is Yes .

Endpoint Configuration

Local Port	Enter the local port number.
Auto increment Local Port for active connect	Select to auto-increment the local port number for new outgoing connections. The range of auto-incremented port numbers is 50,000 to 59,999 and loops back to the beginning when the maximum range is reached. Disabled by default.
Remote Port	Enter the remote port number.
Remote Host	Enter the IP address of the remote device.

Common Options

Telnet Com Port Cntrl	This field is available for configuration only when Active Connect is set to None . Select Enable to permit Telnet communication to the XPress DR+. The Telnet Com Port Cntrl feature is used in conjunction with the Com Port Redirector (CPR) utility. (See the CPR Online Help for details.)
Terminal Name	This field is available for configuration only when Telnet Mode is set to Enable . Use the terminal name for the Telnet terminal type. Enter only one name. When this option is enabled, the unit also reacts to the end of record (EOR) and binary options, which can be used for applications such as terminal emulation to IBM hosts.
Connect Response	A single character is transmitted to the serial port when there is a change in connection state. Default setting is None .

Use Hostlist	<p>If this option is set to Yes, the device server scrolls through the host list until it connects to a device listed in the host list table. Once it connects, the unit stops trying to connect to any others. If this connection fails, the unit continues to scroll through the table until it connects to another IP in the host list.</p> <p>The host list is disabled for Manual Mode and for Modem Mode. The unit will not accept a data connection from a remote device when the host list option is enabled.</p>
LED	Select Blink for the status LEDs to blink upon connection or Off for no LED output. The default setting is Blink .

Disconnect Mode

On Mdm_Ctrl_In Drop	Set to Yes for the network connection to or from the serial port to drop when modem_control_in transitions from a high state to a low state. The default setting is No .
Hard Disconnect	When set to Yes , the TCP connection closes even if the remote site does not acknowledge the disconnect request.
Check EOT (Ctrl-D)	Select Yes to drop the connection when Ctrl-D or Hex 04 is detected. Both Telnet Mode and Disconnect with EOT must be enabled for Disconnect with EOT to function properly. Ctrl+D is only detected going from the serial port to the network. The default setting is No .
Inactivity Timeout	Use this parameter to set an inactivity timeout. The unit drops the connection if there is no activity on the serial line before the set time expires. Enter time in the format <i>mm:ss</i> , where <i>m</i> is the number of minutes and <i>s</i> is the number of seconds. To disable the inactivity timeout, enter 00:00 .

- When finished, click the **OK** button.
- To save and reboot, click **Apply Settings** on the main menu.

Connection Settings - UDP

To configure a channel's UDP settings:

- On the main menu, click **Connection**. The Connection Settings window for the selected channel displays.
- In the available fields, enter or modify the following information:

Figure 5-7. UDP Connection Settings

XPress™ DR+ LANTRONIX®

Connection Settings

Channel 1

Connect Protocol
Protocol:

Datagram Mode:
Datagram Type: Accept Incoming:

Endpoint Configuration:
Local Port: Remote Port:
Remote Host: ☐ Use Broadcast

Device Address Table:

No.	Dev Addr	No.	Dev Addr	No.	Dev Addr	No.	Dev Addr
0	<input type="text" value="0"/>	1	<input type="text" value="0"/>	2	<input type="text" value="0"/>	3	<input type="text" value="0"/>
4	<input type="text" value="0"/>	5	<input type="text" value="0"/>	6	<input type="text" value="0"/>	7	<input type="text" value="0"/>
8	<input type="text" value="0"/>	9	<input type="text" value="0"/>	10	<input type="text" value="0"/>	11	<input type="text" value="0"/>
12	<input type="text" value="0"/>	13	<input type="text" value="0"/>	14	<input type="text" value="0"/>	15	<input type="text" value="0"/>

Connect Protocol

Protocol	Select UDP from the drop-down menu.
-----------------	--

Datagram Mode

Datagram Type	Configures the remote IP or network broadcast address and the remote port. Enter 01 for directed or broadcast UDP. The default setting is 00 .
Accept Incoming	Select Yes to accept incoming UDP datagrams.

Endpoint Configuration

Local Port	Enter the local port number.
Remote Port	Enter the port number of the remote device.
Remote Host	Enter the IP address of the remote device.
Use Broadcast	Check to broadcast the UDP datagram. Datagrams of type 01 can be sent as a broadcast by enabling this option. The default is not to Broadcast (unchecked). <i>Note: Datagrams are sent as subnet-directed broadcasts.</i>
Device Address Table	The table is enabled when Datagram Type is set to FD . Enter values between 1 and 255 to identify the Dev Addr (device address) of units on the local network of device servers.

Note: Lantronix Tech Support supports Datagram type **01**. Datagram Type **FD** is for OEM use.


3. When finished, click the **OK** button.
4. To save and reboot, click **Apply Settings** on the main menu.

Applying Settings

1. To save and apply the configuration changes to the device server, click the **Apply Settings** button. Your configuration changes are saved, and the unit will automatically reboot with new settings applied.

Note: Clicking **OK** on each page does not change the configuration on the device. **OK** tells the XPress DR+ what changes to use; **Apply Settings** makes the changes permanent and reboots the XPress DR+.

Figure 5-8. Apply Settings



Applying Factory Defaults

1. Click the **Apply Defaults** button to set the device server back to the factory default settings. For details see [Default Settings](#).
2. Click **yes** to set factory settings or click **No** to cancel.

6: Configuration Using Telnet/Serial Port (Setup Mode)

As an alternative to using a web browser, as described in the previous chapter, you can use the following procedures remotely or locally:

- ◆ Use a Telnet connection to configure the unit over the network.
- ◆ Use a terminal or terminal emulation program to access the serial port locally.

The series of prompts at which you enter configuration settings is called **Setup Mode**.

Note: Detailed information about other setup methods is available from Lantronix Technical Support (<http://www.lantronix.com/support>). The unit's configuration is stored in nonvolatile memory and is retained without power.

This chapter tells you how to access Setup Mode and the general procedure for using it. To complete the configuration, continue with [7: Setup Mode: Server Configuration](#), [8: Setup Mode: Channel Configuration](#), and [9: Setup Mode: Advanced Settings](#).

Note: The menus in the configuration chapters show a typical device. Your device may have different configuration options. For the latest firmware, release notes, and user documentation, go to the Lantronix web site (www.lantronix.com/downloads).

Accessing Setup Mode

Telnet Connection

To configure the unit over the network, establish a Telnet connection to port 9999.

Note: You can also use *DeviceInstaller* to access Telnet. Select the device from the main window list and click the **Telnet Configuration** tab. Skip steps 1 and 2 below.

To establish a Telnet connection:

1. From the Windows **Start** menu, click **Run** and type the following command, where x.x.x.x is the IP address, and 9999 is the unit's fixed network configuration port number:

```
Windows: telnet x.x.x.x 9999
```

or

```
Unix: telnet x.x.x.x 9999
```

2. Click **OK**. The following information displays.

Figure 6-1. MAC Address

```

*** Lantronix XPress DR+ Industrial Device Server ***
MAC address 0080A38E3C7A
Software version V6.11.0.4 (160916)

Press Enter for Setup Mode

Model: Device Server Plus+! (Firmware Code:rA

```

3. To enter Setup Mode, **press Enter within 5 seconds**. The current configuration settings display, followed by the Change Setup menu.

Figure 6-2. Setup Menu Options

```

Change Setup:
 0 Server
 1 Channel 1
 2 Channel 2
 5 Expert
 6 Security
 7 Defaults
 8 Exit without save
 9 Save and exit           Your choice ?

```

4. Select an option on the menu by entering the number of the option in the **Your choice ?** field and pressing **Enter**.
5. To enter a value for a parameter, type the value and press **Enter**, or to confirm a current value, just press **Enter**.
6. When finished, save the new configuration (option 9). The unit exits and reboots.

Serial Port Connection

To configure the unit through a serial connection:

1. Connect a console terminal (VT100) or PC running a terminal emulation program from port 1 with the Lantronix supplied P/N: 500-103-R RJ45-to-DB9F serial cable.
2. The default serial port settings are 9600 baud, 8 bits, no parity, 1-stop bit, no-flow control.

Note: Reset the XPress DR+ unit by cycling the unit's power (turning the power off and back on). Immediately upon resetting the device, hold down the **x** key at the terminal (or emulation) while resetting the unit. **You must do this within three seconds of resetting the unit.**

3. At this point, the screen display is the same as when you use a Telnet connection. To continue, go to step 3 in *Telnet Connection* above.

Exiting Setup Mode

To exit setup mode, you have two options:

- ◆ To save all changes and reboot the device, select option **9 Save and exit** from the Change Setup menu. All values are stored in nonvolatile memory.
- ◆ To exit the configuration mode without saving any changes or rebooting. Select option **8 Exit without save** from the Change Setup menu.

7: Setup Mode: Server Configuration

This chapter explains how to configure the network settings for the XPress DR+ device server.

Note: Current values display in parentheses.

Server Configuration (Option 0)

You can configure the unit's basic network parameters when you select **Server configuration** (option **0**).

Note: Current values display in parentheses.

IP Address

If DHCP is not used to assign IP addresses, enter the IP address manually. The IP address must be set to a unique value in the network. Enter each octet and press Enter between each section. The current value displays in parentheses.

```
IP Address : (000) . (000) . (000) . (000)
```

If DHCP is used, the third octet of the IP address sets the BootP/DHCP/AutoIP options. The following table shows the bits you can manually configure to force the XPress DR+ to disable AutoIP, DHCP, or BootP. To disable an option, set the appropriate bit.

Table 7-1. BootP/DHCP/AutoIP options

Options	Bit	Value
AutoIP	0	1
DHCP	1	2
BootP	2	4

For example, if the third octet is 0.0.5.0, the AutoIP and BootP options are disabled; only DHCP is enabled. (The value 5 results from adding the binary equivalents of 0 and 2.) This is the most common setting when using DHCP.

Set Gateway IP Address

The gateway address, or router, allows communication to other LAN segments. The gateway address should be the IP address of the router connected to the same LAN segment as the unit. The gateway address must be within the local network. The default setting is **N** (No), meaning the gateway address has not been set. To set the gateway address, type **Y** and enter the address.

```
Set Gateway IP Address (N) ? Y
Gateway IP addr (000) . (000) . (000) . (000)
```

Netmask: Number of Bits for Host Part

A netmask defines the number of bits taken from the IP address that are assigned for the host part.

Netmask: Number of Bits for Host Part (0=default) (0) _

Note: Class A: 24 bits; Class B: 16 bits; Class C: 8 bits

The unit prompts for the number of host bits to be entered, then calculates the netmask, which appears in standard decimal-dot notation (for example, 255.255.255.0) when the saved parameters display.

Table 7-2. Standard IP Network Netmasks

Network Class	Host Bits	Netmask
A	24	255.0.0.0
B	16	255.255.0.0
C	8	255.255.255.0

Set DNS Server IP Address

The DNS server allows the name of a remote machine to be resolved automatically. The default is **N** (No), indicating the DNS server address has not been set. To set the DNS server address, type **Y**. At the prompt, enter the DNS server address. If the device is DHCP enabled, the DHCP server provides the DNS server IP address, which will override this configured value.

Note: This setting is applicable only in Manual Connection mode.

Set DNS Server IP addr (N) ?

Change Telnet Configuration Password

Setting the Telnet configuration password prevents unauthorized access to the setup menu through a Telnet connection to port 9999 or through web pages.

Please protect your device from unauthorized access and follow the instructions below:

- ♦ Always select **Y** to enable Telnet/Web Manager password
- ♦ Enable the enhanced password setting and create a strong 16-character password. For details, see [Security Settings \(Option 6\)](#) on page 68.

Note: We do not recommend that you only use the 4-character basic password as it does not offer sufficient security. Using no password is very dangerous.

Change Telnet/Web Manager password (N) ?

DHCP Name

If a DHCP server has automatically assigned the IP address and network settings, you can discover the unit by using the DeviceInstaller network search feature or Monitor Mode (see [11: Monitor Mode](#)).

Note: When you enter Monitor Mode from the serial port with network connection enabled and issue the NC (Network Communication) command, you see the unit's IP configuration.

There are three methods for assigning DHCP names to the unit.

- ◆ **Default DHCP Name:** If you do not change the DHCP name, and you are using an IP of 0.0.0.0, then the DHCP name defaults to XX.XX.XX.XX (XXXXXX is the last 6 digits of the MAC address shown on the label on the bottom/side of the unit). For example, if the MAC address is 00-20-4A-12-34-56, then the default DHCP name is C123456.
- ◆ **Custom DHCP Name:** You can create your own DHCP name. If you are using an IP address of 0.0.0.0, then the last option in Server configuration is Change DHCP device name. This option allows you to change the DHCP name to an alphanumeric name (LTX in our example).

```
Change DHCP device name (not set) ? (N) Y
Enter new DHCP device name : LTX
```

- ◆ **Numeric DHCP Name:** You can change the DHCP name by specifying the last octet of the IP address. When you use this method, the DHCP name is LTXYY where YY is what you chose for the last octet of the IP address. If the IP address you specify is 0.0.0.12, then the DHCP name is LTX12. This method only works with 2-digit numbers (01-99).

Enable DHCP FQDN Option

A fully qualified domain name (FQDN) is the complete domain name for your device in network. The FQDN consists of two parts, the hostname and the domain name. For example, an FQDN for your device might be [myxport.lantronix.com](#). The hostname is myxport, and the host is located within the domain lantronix.com. The option to enable DHCP FQDN becomes available if DHCP is enabled.

```
Enable DHCP FQDN option : (N)
```

8: Setup Mode: Channel Configuration

This chapter explains how to configure a serial port.

Notes:

- ◆ Current values display in parenthesis.
- ◆ You must enter some values in hexadecimal notation.
(See [E: Binary to Hexadecimal Conversions](#).)

Channel 1 (Option 1) and Channel 2 (Option 2)

Note: Channel 1 and Channel 2 have the same defaults except for the port number (10001 for Channel 1 and 10002 for Channel 2).

Select **Channel 1** (option 1) or **Channel 2** (option 2) from the Change Setup menu to define how the serial port responds to network and serial communications. The following sections describe the configurable parameters within the **Channel** configuration menu.

Figure 8-1. Serial Port Parameters

```
Baudrate (9600) ?
I/F Mode (4C) ?
Flow (00) ?
Port No (10002) ?
ConnectMode (C0) ?
Send '+++' in Modem Mode (Y) ?
Show IP addr after 'RING' (Y) ?
Auto increment source port (N) ?
Remote IP Address : (000) . (000) . (000) . (000)
Remote Port (0) ?
DisConnMode (00) ?
FlushMode (00) ?
DisConnTime (00:00) ? :
SendChar 1 (00) ?
SendChar 2 (00) ?
```

Baudrate

The unit and attached serial device, such as a Programmable Logic Controller (PLC), must agree on a speed or baud rate to use for the serial connection. Valid baud rates are 300, 600, 1200, 2400, 4800, 9600 (default), 19200, 38400, 57600, 115200, and 230400 baud.

```
Baudrate (9600) ? _
```

Interface (I/F) Mode

The Interface (I/F) Mode is a bit-coded byte entered in hexadecimal notation. The default setting is 4C.

I/F Mode (4C) ? _

The following table displays available I/F Mode options.

Note: All bit positions in the table that are blank represent “don’t care” bits for that particular option, which can be set to either a 0 or 1 value.

Table 8-1. Interface Mode Options

I/F Mode Option	7	6	5	4	3	2	1	0
RS-232C ⁽¹⁾							0	0
RS-422/485 4-wire							0	1
RS-485 2-wire							1	1
7 Bit					1	0		
8 Bit					1	1		
No Parity			0	0				
Even Parity			1	1				
Odd Parity			0	1				
1 stop bit	0	1						
2 stop bits ⁽¹⁾	1	1						

⁽¹⁾ 2 stop bits are implemented by the software. This might influence performance.

The following table demonstrates how to build some common Interface Mode settings.

Table 8-2. Common Interface Mode Settings

Common I/F Mode Setting	Binary	Hex
RS-232C, 8-bit, No Parity, 1 stop bit	0100 1100	4C
RS-232C, 7-bit, Even Parity, 1 stop bit	0111 1000	78
RS-485 2-wire, 8-bit, No Parity, 1 stop bit	0100 1111	4F
RS-422, 8-bit, Odd Parity, 1 stop bit	0101 1101	5D

Flow

Flow control sets the local handshaking method for stopping serial input/output. The default setting is 00.

Flow (00) ? _

Use the following table to select flow control options:

Table 8-3. Flow Control Options

Flow Control Option	Hex
No flow control	00
XON/XOFF flow control	01
Hardware handshake with RTS/CTS lines	02
XON/XOFF pass characters to host	05

Port Number

The setting represents the source port number in TCP connections. It is the number that identifies the channel for remote initiating connections.

Port No (10001) ? _

The default setting for port 1 is **10001**. The default setting for Port 2 is **10002**. The range is 1-65535, except for the following reserved port numbers:

Table 8-4. Reserved Port Numbers

Port Numbers	Reserved for
1 – 1024	Reserved (well-known ports)
9999	Telnet setup
14000-14009	Reserved for Redirector
30704	Reserved (77F0h)
30718	Reserved (77FEh)

Warning: We recommend that you not use the reserved port numbers for this setting as incorrect operation may result.

Use Port 0 for the outgoing local port to change with each connection. The port range is 50,000 to 59,999. Each subsequent connection increments the number by 1 (it wraps back around to 50,000).

Only use this automatic port increment feature to initiate a connection using TCP. Set the port to a non-zero value when the unit is in a passive mode or when using UDP instead of TCP.

Connect Mode

Connect Mode defines how the unit makes a connection, and how it reacts to incoming connections over the network.

ConnectMode (C0) ? _

Enter Connect Mode options in hexadecimal notation. The default setting is C0.

Note: All bit positions in the table that are blank represent “don’t care” bits, for that particular option, which can be set to either a 0 or 1 value.

Table 8-5 Connect Mode Options

Connect Mode Option	7	6	5	4	3	2	1	0
a) Incoming Connection								
Never accept incoming	0	0	0					
Accept with active Modem Control In	0	1	0					
Always Accept	1	1	0					
b) Response								
Nothing (quiet)				0				
Character response (C=connect, D=disconnect, N=unreachable)				1				
c) Active Startup								
No active startup					0	0	0	0
With any character					0	0	0	1
With active Modem Control In					0	0	1	0
With a specific start character					0	0	1	1
Manual connection					0	1	0	0
Autostart					0	1	0	1
Hostlist	0	0	1	0				
d) Datagram Type								
Directed UDP					1	1	0	0
e) Modem Mode								
No Echo			0	0		1	1	
Data Echo & Modem Response (Numeric)			0	1		1	1	1
Data Echo & Modem Response (Verbose)			0	1		1	1	0

Connect Mode Option	7	6	5	4	3	2	1	0
Modem Response Only (Numeric)			0	0	1	1	1	1
Modem Response Only (Verbose)			0	0	1	1	1	0

a) Incoming Connection

Never Accept Incoming	Rejects all external connection attempts.
Accept with active Modem Control In	Accepts external connection requests only when the Modem Control In is asserted. Cannot be used with Modem Mode.
Always Accept	Accepts any incoming connection when a connection is not already established. Default setting.

b) Response

Character Response	<p>A single character is transmitted to the serial port when there is a change in connection state: C = connected, D = disconnected, N = host unreachable.</p> <p>Single character mode specifies the character response. The IP address of the host connecting to the unit displays when the unit is in verbose mode. This option is overridden when the Active Start Modem Mode or Active Start Host List is in effect. Default setting is Nothing (quiet).</p>
---------------------------	--

c) Active Startup

No Active Startup	Does <i>not</i> attempt to initiate a connection under any circumstance. Default setting.
With Any Character	Attempts to connect when any character is received from the serial port.
With Active Modem Control In	Attempts to connect when the Modem Control In input changes from not asserted to asserted.
With a Specific Start Character	Attempts to connect when it receives a specific start character from the serial port. The default start character is carriage return.
Manual Connection	<p>Attempts to connect when directed by a command string received from the serial port. The first character of the command string must be a C (ASCII 0x43), and the last character must be either a carriage return (ASCII 0x0D) or a line feed (0x0A). No blanks or space characters may be in the command string. Between the first and last command string characters must be a full or partial destination IP address and may be a destination port number.</p> <p>The IP address must be in standard decimal-dot notation and may be a partial address, representing the least significant 1, 2, or 3 bytes of the remote IP address. The period is required between each pair of IP address numbers.</p> <p>If present, the port number must follow the IP address, must be presented as a decimal number in the range 1-65535, and must be preceded by a forward slash (ASCII 0x2F). The slash</p>

	<p>separates the IP address and the port number. If you omit the port number from a command string, the internally stored remote port number starts a connection.</p> <p>If a partial IP address is presented in a command string, it is interpreted to be the least significant bytes of the IP address and uses the internally stored remote IP address to provide the most significant bytes of the IP address. If the IP address entered is 0.0.0.0/0, the device server enters Monitor Mode.</p> <p>For example, if the remote IP address already configured in the unit is 129.1.2.3, then an example command string would be C3/7. (This would connect to 129.1.2.3 and port 7.) You may also use a different ending for the connection string. For example, C50.1/23 would connect you to 129.1.50.1 and port 23. If an IP address does not follow the first command string character (which is "C"), the subsequent character string is interpreted as the host name and domain to be used in DNS lookup. This character string can include a destination port number as well. The port number can be preceded by either a forward slash (/) or a colon (:).</p>
--	---

Table 8-6 Manual Connection Address Example

Command String	Result if remote IP is 129.1.2.3 and remote port is 1234
C121.2.4.5/1	Complete override; connection is started with host 121.2.4.5, port 1
C5	Connects to 129.1.2.5, port 1234
C28.10/12	Connects to 129.1.28.10, port 12
C0.0.0.0/0	Enters Monitor Mode
Cwww.lantronix.com/80	Tries to connect to the Lantronix web server if the <hostname:domain> (www.lantronix.com) is configured in the DNS server database

Autostart (Automatic Connection)	If you enable Autostart , the unit automatically connects to the remote IP address and remote port specified when the firmware starts.
Hostlist	<p>If you enable this option, the device server scrolls through the host list until it connects to a device listed in the host list table. Once it connects, the unit stops trying to connect to any others. If this connection fails, the unit continues to scroll through the table until it is able to connect to another IP in the host list.</p> <p>Hostlist supports a minimum of 1 and a maximum of 12 entries. Each entry contains the IP address and the port number. The host list is disabled for Manual and Modem Modes. The unit does not accept a data connection from a remote device when the host list option is enabled.</p>

Figure 8-2 Hostlist Option

```

Baud rate (9600) ?
I/F Mode (4C) ?
Flow (00) ?
Port No (10001)?
ConnectMode (25) ?
Send '+++\' in Modem Mode (?) ?

Auto increment source port (N) ?

Hostlist :
01. IP : 172.019.000.001 Port : 00023
02. IP : 172.019.000.002 Port : 03001
03. IP : 172.019.000.003 Port : 10001

Change Hostlist ? (N) ? Y
01. IP address : (172) .(019) .(000) .(001) Port : (23) ?
02. IP address : (172) .(019) .(000) .(002) Port : (3001) ?
03. IP address : (172) .(019) .(000) .(003) Port : (10001) ?
04. IP address : (000) .(000) .(000) .(000)

Hostlist :
01. IP : 172.019.000.001 Port : 00023
02. IP : 172.019.000.002 Port : 3001
03. IP : 172.019.000.003 Port : 10001

Change Hostlist ? (N) ? N
Hostlist Retrycounter (3) ?
Hostlist Retrytimeout (250) ?
DisConnMode (00) ?
FlushMode (00) ?
DisConnTime (00:00) ? :
SendChar 1 (00) ?
SendChar 2 (00) ? _

```

To enable the hostlist:

1. Enter a **Connect Mode** of 0x20 (2X), where X is any digit. The menu shows you a list of current entries already defined in the product.
2. To delete, modify, or add an entry, select **Yes**. If you enter an IP address of **0.0.0.0**, that entry and all others after it are deleted.
3. After completing the host list, repeat the previous step if necessary to edit the host list again.
4. For **Retrycounter**, enter the number of times the Lantronix unit should try to make a good network connection to a host list entry that it has successfully ARPed. The range is 1-15, with the default set to **3**.
5. For **Retrytimeout**, enter the number of seconds the unit should wait before failing an attempted connection. The time is stored as units of milliseconds in the range of 1-65535. The default setting is **250**.

d) Datagram Type

Directed UDP	<p>When selecting this option, you are prompted for the Datagram type. Enter 01 for directed or broadcast UDP.</p> <p>When the UDP option is in effect, the unit never attempts to initiate a TCP connection because it uses UDP datagrams to send and receive data.</p>
---------------------	---

e) Modem Mode

In Modem (Emulation) Mode, the unit presents a modem interface to the attached serial device. It accepts AT-style modem commands and handles the modem signals correctly.

Normally, there is a modem connected to a local PC and a modem connected to a remote machine. A user must dial from the local PC to the remote machine, accumulating phone charges for each connection. Modem Mode allows you to replace modems with XPress DR+ units, and to use an Ethernet connection instead of a phone call. By not having to change communications applications, you avoid potentially expensive phone calls.

To select Modem Mode, set the Connect Mode to **C6** (no echo), **D6** (echo with full verbose), **D7** (echo with numeric response), **CF** (modem responses only, numeric response), or **CE** (modem responses only, full verbose).

Note: If the unit is in Modem Mode, and the serial port is idle, the unit can still accept network TCP connections to the serial port if Connect Mode is set to **C6** (no echo), **D6** (echo with full verbose), **D7** (echo with numeric response), **CF** (modem responses only, numeric response), or **CE** (modem responses only, full verbose).

Without Echo	In Modem Mode, echo refers to the echo of all of the characters entered in command mode; it does <i>not</i> mean to echo data that is transferred. Quiet Mode (without echo) refers to the modem <i>not</i> sending an answer to the commands received (or displaying what was typed).
Data Echo & Modem Response	<p>Full Verbose: The unit echoes modem commands and responds to a command with a message string shown in the table below.</p> <p>Numeric Response: The unit echoes modem commands and responds to a command with a numeric response.</p>
Modem Responses Only	<p>Full Verbose: The unit does not echo modem commands and responds to a command with a message string shown in the table below.</p> <p>Numeric Response: The unit does not echo modem commands and responds to a command with a numeric response.</p>

Table 8-7 Modem Mode Messages

Message	Meaning
Full Verbose	
OK	Command was executed without error.
CONNECT	A network connection has been established.
NO CARRIER	A network connection has been closed.
RING n.n.n.n.	A remote device, having IP address n.n.n.n, is connecting to this device.
Numeric Response	
0	OK
1	Connected
2	Ring
3	No Carrier
4	Error

Received commands must begin with the two-character sequence **AT** and be terminated with a carriage return character.

The unit ignores any character sequence received *not* starting with **AT**, and only recognizes and processes single **AT**-style commands. The unit treats compound **AT** commands as unrecognized commands.

If the **Full Verbose** option is in effect, the unit responds to an unrecognized command string that is otherwise formatted correctly (begins with **AT** and ends with carriage return) with the "OK" message and takes no further action.

If the **Numeric Response** option is in effect, the unit responds to an unrecognized command string that is otherwise formatted correctly with the "0" message and takes no further action.

When an active connection is in effect, the unit transfers data and does not process commands received from the serial interface.

When a connection is terminated or lost, the unit reverts to command mode.

When an active connection is in effect, the unit terminates the connection if it receives the following sequence from the attached serial device:

- ◆ No serial data is received for one second.
- ◆ The character sequence +++ is received, with no more than one second between each two characters.
- ◆ No serial data is received for one second after the last + character. At this time, the unit responds affirmatively per the selected echo/response mode.

- ◆ The character string **ATH** is received, terminated with a carriage return. The unit responds affirmatively according to the selected echo/response mode and drops the network connection. The serial interface reverts to accepting command strings.

If this sequence is not followed, the unit remains in data transfer mode.

Table 8-8 Modem Mode Commands

Modem Mode Command	Function
ATDTx.x.x.x,pppp or ATDTx.x.x.x/pppp or ATDTx.x.x.x:pppp	Makes a connection to an IP address (x.x.x.x) and a remote port number (pppp).
ATDTx.x.x.x	Makes a connection to an IP address (x.x.x.x) and the remote port number defined within the unit.
ATD0.0.0.0	Forces the unit into Monitor Mode if a remote IP address and port number are defined within the unit.
ATD or ATDT	Forces the unit into Monitor Mode if a remote IP address and port number are not defined within the unit.
ATDx.x.x.x	Makes a connection to an IP address (x.x.x.x) and the remote port number defined within the unit.
ATH	Hangs up the connection (entered as +++ATH).
ATS0=n	Enables or disables connections from the network going to the serial port. <ul style="list-style-type: none"> ◆ n=0 disables the ability to make a connection from the network to the serial port. ◆ n=1-9 enables the ability to make a connection from the network to the serial port. ◆ n>1-9 is invalid.
ATEn	Enables or disables character echo and responses. <ul style="list-style-type: none"> ◆ n=0 disables character echo and responses. ◆ n=1 enables character echo and responses.
ATVn	Enables numeric response or full verbose. <ul style="list-style-type: none"> ◆ n=0 enables numeric response. ◆ n=1 enables full verbose.

Note: The unit recognizes these AT commands as single commands such as ATE0 or ATV1; it does not recognize compound commands such as ATE0V.

Send the Escape Sequence (+++) in Modem Mode

Send '+++' in Modem Mode (Y)? _

Disable or enable the unit's ability to send the escape sequence. The default is **Y** (Yes) (send the escape sequence).

Show IP Address After Ring

Show IP addr after 'RING' (Y) ?

Disable or enable the XPress DR+ device's ability to show the IP address after RING in Modem Mode. The default is Y (Yes), to show the IP address.

Auto Increment Source Port

Auto increment source port (N) ? _

Y (Yes) auto increments the source port. The XPress DR+ increments the port number used with each new connection.

Remote IP Address

This is the destination IP address used with an outgoing connection.

Remote IP Address: (000) (000) (000) (000) _

Note: This option does not display when Hostlist is enabled from the **ConnectMode** prompt (see [Connect Mode](#) for more information).

Remote Port

You must set the remote TCP port number for the unit to make outgoing connections. This parameter defines the port number on the target host to which a connection is attempted.

Remote Port (0) ? _

To connect an ASCII terminal to a host using the unit for login purposes, use the remote port number 23 (Internet standard port number for Telnet services).

Note: This option does not display when Hostlist is enabled from the **ConnectMode** prompt (see [Connect Mode](#) for more information).

DisConnMode

This setting determines the conditions under which the unit will cause a network connection to terminate. The default setting is 00.

DisConnMode (0) ? _

Note: In DisConnMode (Disconnect Mode), DTR drop either drops the connection or is ignored. All bit positions in the table that are blank represent "don't care" bits, for that particular option, which can be set to either a 0 or 1 value.

Table 8-9 Disconnect Mode Options

Disconnect Mode Option	7	6	5	4	3	2	1	0
Disconnect when Modem Control In is not asserted ⁽⁶⁾	1							
Ignore Modem Control In	0							
Telnet Com Port Cntrl and terminal type setup ⁽¹⁾		1						
Channel (port) password ⁽²⁾				1				
Hard disconnect ⁽³⁾					0			
Disable hard disconnect					1			
State LED off with connection ⁽⁴⁾								1
Disconnect with EOT (^D) ⁽⁵⁾			1					

(1) The Telnet Com Port Control feature is used in conjunction with Com Port Redirector.

The XPress DR+ sends the "Terminal Type" upon an outgoing connection.

(2) A password is required for a connection to the serial port from the network.

(3) The TCP connection closes even if the remote site does not acknowledge the disconnection.

(4) When there is a network connection to or from the serial port, the state LED turns off instead of blinking.

(5) When Ctrl+D or Hex 04 is detected, the connection is dropped. Both Telnet Mode and Disconnect with EOT must be enabled for Disconnect with EOT to function properly. Ctrl+D is only detected going from the serial port to the network.

(6) When Modem Control In transitions from a high to low state, the network connection to or from the serial port drops.

Flush Mode (Buffer Flushing)

Using this parameter, you can control line handling and network buffers with connection startup and disconnect. The default setting is 00. You can also select between two different packing algorithms.

FlushMode (0) ? _

Note: All bit positions in the table that are blank represent "don't care" bits, for that particular option, which can be set to either a 0 or 1 value.

Table 8-10 Flush Mode Options

Function	7	6	5	4	3	2	1	0
Input Buffer (Serial to Network)								
Clear with a connection initiated from the device to the network				1				
Clear with a connection initiated from the network to the device			1					

Function	7	6	5	4	3	2	1	0
Clear when the network connection to or from the device is disconnected		1						
Output Buffer (Network to Serial)								
Clear with a connection initiated from the device to the network								1
Clear with a connection initiated from the network to the device							1	
Clear when the network connection to or from the device is disconnected						1		
Alternate Packing Algorithm (Pack Control)								
Enable	1							

Pack Control

The packing algorithms define how and when packets are sent to the network. The standard algorithm is optimized for applications in which the unit is used in a local environment, allowing for very small delays for single characters, while keeping the packet count low. The alternate packing algorithm minimizes the packet count on the network and is especially useful in applications in a routed Wide Area Network (WAN). Adjusting parameters in this mode can economize the network data stream.

Pack control settings are enabled in Flush Mode. Set this value to **00** if you do not need specific functions.

Note: All bit positions in the table that are blank represent “don’t care” bits, for that particular option, which can be set to either a 0 or 1 value.

Table 8-11 Pack Control Options

Option	7	6	5	4	3	2	1	0
Packing Interval								
Interval: 12ms							0	0
Interval: 52ms							0	1
Interval: 250ms							1	0
Interval: 5sec							1	1
Trailing Characters								
None					0	0		
One					0	1		
Two					1	0		
Send Characters								
2-Byte Send Character Sequence				1				
Send Immediately After Send chars			1					

Packing Interval

Packing Interval defines how long the unit should wait before sending accumulated characters. This wait period is between successive network segments containing data. For alternate packing, the default interval is **12 ms**.

Trailing Characters

In some applications, CRC, Checksum, or other trailing characters follow the end-of-sequence character; this option helps to adapt frame transmission to the frame boundary.

Send Characters

- ◆ If **2-Byte Send Character Sequence** is enabled, the unit interprets the sendchars as a 2-byte sequence; if this option is not enabled, the unit interprets them independently.
- ◆ If **Send Immediately After Characters** is *not* set, any characters already in the serial buffer are included in the transmission after a "transmit" condition is found. If this option is set, the unit sends immediately after recognizing the transmit condition (sendchar or timeout).

Note: A transmission might occur if status information needs to be exchanged or an acknowledgment needs to be sent.

DisConnTime (Inactivity Timeout)

Use this parameter to set an inactivity timeout. The unit drops the TCP connection to port 10001/10002 if there is no activity on the serial line before the set time expires. Enter time in the format mm:ss, where m is the number of minutes and s is the number of seconds. To disable the inactivity timeout, enter 00:00.

DisConnTime (0: 0)?:

To disable the inactivity timeout, enter **00:00**. Range is 0 (disabled) to 5999 seconds (99 minutes, 59 seconds). Default setting is **0**.

Send Characters

Enter up to two characters in hexadecimal representation in sendchar.

SendChar 1 (0) ? _
 SendChar 2 (0) ? _

If the unit receives a character on the serial line that matches one of these characters, it sends the character immediately, along with any awaiting characters, to the TCP connection. This action minimizes the response time for specific protocol characters on the serial line (for example, ETX, EOT). Setting the first sendchar to **00** disables the recognition of the characters. Alternatively, the unit can interpret two characters as a sequence (see [Pack Control](#)).

Telnet Terminal Type

This parameter displays only if you enabled the terminal type option in Disconnect Mode. When enabled, you can use the terminal name for the Telnet terminal type. Enter only one name.

`Terminal name () ?`

With terminal type option enabled, the unit also reacts to the EOR (end of record) and binary options, useful for applications like terminal emulation to IBM hosts.

Channel (Port) Password

This parameter appears only if the channel (port) password option is enabled in Disconnect Mode. With this option enabled, you can set a password on the serial port.

9: Setup Mode: Advanced Settings

Expert Settings (Option 5)

Note: You can change these settings using Telnet or serial connections only, not on the Web Manager.

Caution: Changing the expert settings can drastically affect the performance and access to the product. These settings should only be changed by an experienced network administrator.

Figure 9-1. Expert Settings

```
TCP Keepalive time in s (1s - 65s; 0s=disable): (45)?  
ARP Cache timeout in s (0s - 600s) : (600)?  
Disable Monitor Mode @ bootup (N)?  
HTTP Port Number: (80) ?  
MTU Size (512 - 1400): (1400)?  
TCP Re-transmission Timeout (500 - 4000) (ms): (500)?  
Enable alternate MAC (N)?
```

TCP Keepalive time in seconds

This option allows you to change how many seconds the unit waits during a silent connection before attempting to see if the currently connected network device is still on the network. If the unit gets no response, it drops that connection. The default setting is **45**.

```
TCP Keepalive time in s (1s - 65s; 0s=disable): (45)? _
```

ARP Cache timeout in seconds

Whenever the unit communicates with another device on the network, it adds an entry into its ARP table. The **ARP Cache timeout** option allows you to define how many seconds (1-600) the unit will wait before timing out this table. The default setting is **600**.

```
ARP Cache timeout in s (0s - 600s): (600)? _
```

Disable Monitor Mode at bootup

This option allows you to disable all entries into Monitor Mode during startup, except for the **xxx** sequence. This prevents entry using **yyy**, **zzz**, **xx1**, and **yy1** key sequences (only during the bootup sequence). The default setting for Monitor Mode at bootup is **N** (No). (See [11: Monitor Mode](#).)

```
Disable Monitor Mode @ bootup (N)? _
```

HTTP Port Number

This option allows the configuration of the web server port number. The valid range is 1-65535. The default HTTP port number is **80**.

```
HTTP Port Number: (80) ? _
```

MTU Size

The Maximum Transmission Unit (MTU) is the largest physical packet size a network can transmit for TCP and UDP. Enter between **512** and **1400** bytes. The default setting is **1400** bytes.

```
MTU Size (512 -1400): (1400)? _
```

TCP Re-transmission Timeout

This feature allows the configuration of the desired TCP re-transmission timeout value. If the ACK is not received for a packet sent from the XPress Direct+ device, then the unit will retransmit the data. The valid range is 500-4000 msec with 500 msec as default.

```
TCP Re-transmission Timeout (500 - 4000) (ms): (500)?
```

Enable alternate MAC

If necessary, enable the alternate MAC address (if specified in the OEM setup record). The default setting is **N** (No).

```
Enable alternate MAC (N)? _
```

Security Settings (Option 6)

You can change security settings by means of Telnet or serial connections only, not on the Web Manager. We recommend that you set security over the dedicated network or over the serial setup to prevent eavesdropping.

Caution: *Disabling both Telnet Setup and Port 77FE will prevent users from accessing Setup Mode from the network. Disabling Port 77FE also disables the Web Manager and DeviceInstaller from configuring the device.*

Select **6** to configure security settings.

Figure 9-2. Security Settings

```
Disable SNMP (N)?
SNMP Community Name (public):
Disable Telnet Setup (N)?
Disable TFTP Firmware Update (N)?
```

```

Disable Port 77FEh (N)?
77FEh Access Mode (0=Read & Write, 1=Read Only): (0)?
Disable Web Server (N)?
Disable Web Setup (N)?
Disable ECHO ports (Y)?
Enable Enhanced Password (N)?

```

Disable SNMP

This setting allows you to disable the SNMP protocol on the unit for security reasons. The default setting is **N** (No).

```
Disable SNMP (N)? _
```

SNMP Community Name

The SNMP Community Name is a required field for NMS to read or write to a device. Enter a string of 1 to 13 characters. The default setting is **public**.

```
SNMP Community Name (public): _
```

The default entry is **public**. The current value is displayed in parentheses.

Disable Telnet Setup

Note: If you choose to disable this option, keep in mind that disabling both **Telnet Setup** and **Port 77FE** will prevent users from accessing Setup Mode from the network.

This setting defaults to the **N** (No) option. The **Y** (Yes) option disables access to Setup Mode by Telnet (port 9999). It only allows access locally using the web pages and the serial port of the unit.

```
Disable Telnet Setup (N)? _
```

Disable TFTP Firmware Upgrade

This setting defaults to the **N** (No) option. The **Y** (Yes) option disables the use of TFTP to perform network firmware upgrades. With this option, you can download firmware upgrades over the serial port using DeviceInstaller's Recover Firmware procedure. (See [10: Firmware Upgrades](#) and the DeviceInstaller online Help.

```
Disable TFTP Firmware Update (N): _
```

Disable Port 77FE (Hex)

Note: If you choose to disable this option, keep in mind that disabling both **Telnet Setup** and **Port 77FE** will prevent users from accessing Setup Mode from the network.

Port 77FE is a setting that allows DeviceInstaller, Web Manager, and custom programs to configure the unit remotely. You may wish to disable this capability for security purposes.

Disable Port 77FEh (N)? _

The default setting is the **N** (No) option, which enables remote configuration. You can configure the unit by using DeviceInstaller, Web Manager, Telnet, or serial configuration.

The **Y** (Yes) option disables remote configuration and web sites.

Note: The **Y** (Yes) option disables many of the GUI tools for configuring the unit, including the embedded Web Manager tool.

77FEh Access Mode

Configuring this setting is available if port 77FE is enabled. This option will not be listed if port 77FE is disabled.

Set 0 for Read & Write mode, and 1 for Read Only mode. Default value of this setting is Read-Write(0).

If access mode is Read-only, then read operation can be done through port 77FE, if Read-Write access is selected, then both read and write of data can be done through port 77FE.

77FEh Access Mode (0=Read & Write, 1=Read Only): (0) ?

Disable Web Server

This setting defaults to the **N** (No) option. The **Y** (Yes) option disables the web server.

Disable Web Server (N) ? _

Disable Web Setup

The **Y** (Yes) option disables configuration using the Web Manager. This setting defaults to the **N** (No) option.

Disable Web Setup (N) ? _

Disable ECHO Ports

This setting controls whether port 7 echoes characters it receives. The default setting is **Y** (Yes), which disables ECHO ports.

Disable ECHO ports (Y) ? _

Enable Enhanced Password

The Enhanced Password setting allows you to set a password of up to 16 characters for protecting Telnet and Web Page access. We recommend that you select the **Y** (Yes) option and enable the enhanced password setting.

Avoid using either the 4-character basic password setting or no password at all as they are not secure options.

Enable Enhanced Password (Y) ? _

Default Settings (Option 7)

Select **7** to reset the unit's channel configuration, email settings, and expert settings to the default settings. The server configuration settings for IP address, gateway IP address, and netmask remain unchanged. The specific settings that this option changes are listed below.

Channel 1 and Channel 2 Configuration Settings

Baudrate	9600
I/F Mode	4C (1 stop bit, no parity, 8-bit, RS-232C)
Own TCP port number	Channel 1: 10001 Channel 2: 10002
Connect Mode	C0 (always accept incoming connection; no active connection startup)
Hostlist retry counter	3
Hostlist retry timeout	250 (msec)
Start character for serial channel 1	0x0D (CR)
All other parameters	0

Expert Settings

TCP Keepalive time in s	45
ARP Cache timeout in s	600
Disable Monitor Mode @ bootup	No
HTTP Port Number (1-65535)	80
MTU Size (512 – 1400)	0 (resulting in an operational value of 1400)
Enable alternate MAC	No (for OEM use only)
TCP Re-transmission Timeout (500-4000)	500 (ms)

Security Settings

Disable SNMP	No
SNMP community name	public
Disable Telnet setup	No
Disable TFTP Firmware Update	No
Disable Port 77FEh	No
Disable Web Server	No
Disable Web Setup	No
Disable ECHO ports	Yes
Enable Enhanced password	Yes
Enable Telnet Authentication	No

10: Firmware Upgrades

Obtaining Firmware

You can obtain the most up-to-date firmware and release notes for the unit from the Lantronix web site (www.lantronix.com) or by using anonymous FTP ([ftp.lantronix.com](ftp://ftp.lantronix.com)).

Reloading Firmware

There are several ways to update the unit's internal operational code (*.ROM): using DeviceInstaller (the preferred way), using TFTP, or using the serial port. You can also update the unit's internal web interface (*.COB) using TFTP or DeviceInstaller.

Here are *typical* names for those files. Check the Lantronix web site for the latest versions and release notes.

Table 10-1. Firmware Files

ROM File	COB
AQDR_61104.ROM	XDRPL_WEBM_20010.COB

Please refer to the DeviceInstaller online Help for information about reloading firmware using DeviceInstaller. The other methods are discussed below.

Using TFTP: Graphical User Interface


To download new firmware from a computer:

1. Use a TFTP client to send a binary file to the unit (*.ROM to upgrade the unit's internal operational code and *.COB to upgrade its internal web interface).

Note: TFTP requires the .ROM (binary) version of the unit's internal operational code.

2. In the **TFTP server** field, enter the IP address of the unit being upgraded.
3. Select **Upload** operation and **Binary** format.
4. Enter the full path of the firmware file in the **Local file name** field.
5. In the **Remote file name** field, enter the current internal operational code (**rA** for XPress DR+) or **WEB1** for the internal web pages.
6. Click the **Upload Now** button to transfer the file to the unit.

Figure 10-1. TFTP Window



After the firmware has been loaded and stored, which takes approximately 8 seconds to complete, the unit performs a power reset.

Using TFTP: Command Line Interface

To download new firmware from a computer:

Enter the following from a TFTP command line interface:

```
tftp -i <ip address> put <local filename> <destination file name>
```

The following examples demonstrate the TFTP command sequence to download the .ROM file and the .COB file:

1. In the **Remote file name** field, enter the current internal operational code (**rA** for XPress DR+) or **WEB1** for the internal web pages.

```
tftp -i 192.168.1.111 put aqdr_61104.rom rA
tftp -i 192.168.1.111 put xdrpl_webm_20010.cob WEB1
```

Recovering the Firmware Using the Serial Port and DeviceInstaller

If for some reason the firmware is damaged, you can recover the firmware file by using DeviceInstaller (v. 4.4.0.2 or later) to download the *.ROM file over the serial port.

To recover firmware:

1. Start **DeviceInstaller**. If your PC has more than one network adapter, a message displays. Select an adapter and click **OK**.
2. From the **Tools** menu, select **Advanced/Recover Firmware**. The Serial Port Firmware Upgrade window displays.

3. For Port on PC, enter the COM port on the PC that is connected to the serial port of the Lantronix unit.
4. For Device Model, be sure the appropriate XPress DR+ device displays.
5. For Firmware File, click the **Browse** button and go to the location where the firmware file resides.

Note: Make sure the XPress DR+ unit on which you are recovering firmware is connected to this selected port on your PC.

6. Click **OK** to download the file.
7. When prompted, reset the device. Status messages and a progress bar at the bottom of the screen show the progress of the file transfer. When the file transfer completes, the message "Successful, Click **OK** to Close" appears.
8. Click the **OK** button to complete this procedure.

Note For more information, see *Recovering Firmware in the DeviceInstaller online Help*.

11: Monitor Mode

Monitor Mode is a command line interface used for diagnostic purposes.

There are two ways to enter Monitor Mode: locally using the serial port or remotely using the network.

Entering Monitor Mode Using the Serial Port

1. Follow the same steps used for setting the serial configuration parameters (see [Serial Port](#)).
2. Instead of typing three **x** keys, however:
 - a) Type **zzz** (or **xx1**) to enter Monitor Mode with network connections.
 - b) Type **yyy** (or **yy1**) to enter Monitor Mode without network connections.
3. A **0>** prompt indicates that you have successfully entered Monitor Mode.

Entering Monitor Mode Using the Network Port

1. Establish a Telnet session to the configuration port (9999).
2. Type **M** (upper case). A **0>** prompt indicates that you have successfully entered Monitor Mode.

Figure 11-1. Accessing Monitor Mode

```
*** Lantronix XPress DR+ Industrial Device Server ***
MAC address 0080A38E3C7A
Software version V6.11.0.4 (160916)

Press Enter for Setup Mode
```

Monitor Mode Commands

The following commands are available in Monitor Mode. Many commands have an IP address as an optional parameter (xxx.xxx.xxx.xxx). If you enter the IP address, the command is applied to another unit with that IP address. If you do not enter the IP address, the command is executed locally.

Note: All commands must be in capital letters.

Table 11-1. Monitor Mode Commands

Command	Command Name	Function
AT	ARP Table	Shows the unit's ARP table entries.
co	Set IP address, host bits, gateway, and DNS server IP	Example: co 192.168.0.10 8 192.168.0.1 10001 192.168.1.10 with 192.168.0.10 = IP address of the XPress DR+ 8 = number of host bits 192.168.0.1 = gateway IP address 10001 = port number of the XPress DR+ 192.168.1.10 = IP address of the DNS Server The XPress DR+ stores the setup and performs a reset. It sends an X before the reset if the command was OK.
G0, G1, ...,Ge, Gf	Get configuration from memory page	Gets a memory page of configuration information from the device for setup record 0 to15.
GC x.x.x.x	Get Configuration	Gets configuration of unit with IP address x.x.x.x as hex records (120 bytes).
GM	Get MAC address	Shows the unit's 6-byte MAC address.
NC	Network Connection	Shows the unit's current IP address, gateway, subnet mask, and DNS server.
NS	Network Status	Reports the network interfaces' statuses. Includes potentially negotiated parameters like speed/duplex for Ethernet or BSSID, encryption, authentication for wireless interfaces.
PI x.x.x.x	Ping	Pings unit with IP address x.x.x.x to check device status.
QU	Quit	Exits diagnostics mode.
R0, R1, ...,Rb, Rc	Get configuration from memory page	Gets a memory page of configuration information from the device for setup record 16 to 28.
RS	Reset	Resets the unit's power.
S0, S1,...,Se, Sf	Set configuration to memory page	Sets a memory page of configuration information on the device for setup record 0 to15.
SA	Scan	Initiates a wireless scan if the wireless interface is enabled. Reports any stations found, including BSSID, SSID, and RSSI. If SA is followed by a string, the string is used to filter SSIDs before reporting. If the BSS does not broadcast its SSID, only the BSSID and RSSI are returned.
SC x.x.x.x	Send Configuration	Sets configuration of unit with IP address x.x.x.x from hex records.
SS	Set Security record	Sets the Security record without the encryption key and length parameters. The entire record must still be written, but the encryption-specific bytes do not need to be provided (they can be null since they are not overwritten).

Command	Command Name	Function
TT	TCP Connection Table	Shows all incoming and outgoing TCP connections.
VN	Query full firmware version	This command queries and displays full firmware version in readable string format.
VS x.x.x.x	Version	Queries software header record (16 bytes) of unit with IP address x.x.x.x.
W0, W1, ..., Wb, Wc	Set configuration to memory page	Sets a memory page of configuration information on the device for setup record 16 to 28.

Responses to some of the commands are in Intel Hex format.

Note: Entering any of the commands listed above generates one of the following command response codes

Table 11-2. Command Response Codes

Response	Meaning
0>	OK; no error
1>	No answer from remote device
2>	Cannot reach remote device or no answer
8>	Wrong parameter(s)
9>	Invalid command

12: Troubleshooting

This chapter discusses how you can diagnose and fix errors quickly without having to contact a dealer or Lantronix. It helps to connect a terminal to the serial port while diagnosing an error to view summary messages that may display. When troubleshooting, always ensure that the physical connections (power cable, network cable, and serial cable) are secure.

Note: Some unexplained errors might be caused by duplicate IP addresses on the network. Make sure that your unit's IP address is unique.

When troubleshooting the following problems, make sure that the unit is powered up. Confirm that you are using a good network connection.

Problems and Error Messages

Note: For information about diagnostic LEDs, see [LEDs](#).

Table 12-1. Problems and Error Messages

Problem/Message	Reason	Solution
When you issue the ARP -S command in Windows, the "ARP entry addition failed: 5" message displays.	Your currently logged-in user does not have the correct rights to use this command on this PC.	Have someone from your IT department log you in with sufficient rights.
When you attempt to assign an IP address to the unit by the ARP method, the "Press Enter to go into Setup Mode" error "(described below) message displays. Now when you Telnet to the device server, the connection fails.	When you Telnet to port 1 on the device server, you are only assigning a temporary IP address. When you Telnet into port 9999 and do not press Enter quickly, the device server reboots, causing it to lose the IP address.	Telnet back to port 1. Wait for it to fail, then Telnet to port 9999 again. Make sure you press Enter quickly.
When you Telnet to port 9999, the "Press Enter to go into Setup Mode" message displays. However, nothing happens when you press Enter , or your connection closes.	You did not press Enter quickly enough. You only have 5 seconds to press Enter before the connection closes.	Telnet to port 9999 again, but press Enter as soon as you see the "Press Enter to go into Setup Mode" message.
When you Telnet to port 1 to assign an IP address to the device server, the Telnet window does not respond for a long time.	You may have entered the Ethernet address incorrectly with the ARP command.	Confirm that the Ethernet address that you entered with the ARP command is correct. The Ethernet address may only include numbers 0-9 and letters A-F. In Windows and usually in Unix, the segments of the Ethernet address are separated by dashes. In some forms of Unix, the Ethernet address is segmented by colons.

Problem/Message	Reason	Solution
	The IP address you are trying to assign is not on your logical subnet.	Confirm that your PC has an IP address and that it is in the same logical subnet that you are trying to assign to the device server.
	The device server may not be plugged into the network properly.	Make sure that the Link LED is lit. If the Link LED is not lit, then the device server is not properly plugged into the network.
When you try to assign an IP with DeviceInstaller, you get the following : "No response from device! Verify the IP, Hardware Address and Network Class. Please try again."	The cause is most likely one of the following: The hardware address you specified is incorrect. The IP address you are trying to assign is not a valid IP for your logical subnet. You did not choose the correct subnet mask.	Double-check the parameters that you specified. Note: You cannot assign an IP address to a device server through a router.
The device server is not communicating with the serial device to which it is attached.	The most likely reason is the wrong serial settings were chosen.	The serial settings for the serial device and the device server must match. The default serial settings for the device server are RS-232, 9600 baud, 8 character bits, no parity, 1 stop bit, no flow control.
When you try to enter the setup mode on the device server using the serial port, you get no response.	The issue is most likely something covered in the previous problem, or possibly, you have Caps Lock on.	Double-check everything in the problem above. Confirm that Caps Lock is not on.
You can ping the device server, but not Telnet to the device server on port 9999.	There may be an IP address conflict on your network You are not Telnetting to port 9999. The Telnet configuration port (9999) is disabled within the device server security settings.	Turn the device server off and then issue the following commands at the DOS prompt of your computer: ARP -D X.X.X.X (X.X.X.X is the IP of the device server). PING X.X.X.X (X.X.X.X is the IP of the device server). If you get a response, then there is a duplicate IP address on the network. If you do not get a response, use the serial port to verify that Telnet is not disabled.

Problem/Message	Reason	Solution
The device server appears to be set up correctly, but you are not communicating with your device attached to the device server across the network.	<p>If you are sure that the serial port setting is correct, then you may not be connecting to the correct socket of the device server.</p> <p>Another possibility is that the device server is not set up correctly to make a good socket connection to the network.</p>	Use the Connect Mode option C0 for making a connection to the device server from the network. Use Connect Mode option C1 or C5 for a connection to the network from the device server.
When connecting to the Web Manager within the device server, the "No Connection with the Device Server" message displays.	Your computer is not able to connect to port 30718 (77FEh) on the device server.	Make sure that port 30718 (77FEh) is not blocked with any router that you are using on the network. Also, make sure that port 77FEh is not disabled within the Security settings of the device server.

A. Technical Support

Lantronix offers many resources to support our customers and products at <http://www.lantronix.com/support>. For instance, you can ask a question, find firmware downloads, access the FTP site and search through tutorials. At this site you can also find FAQs, bulletins, warranty information, extended support services and product documentation.

To contact technical support or sales, look up your local office at <http://www.lantronix.com/about/contact.html>. When you report a problem, please provide the following information:

- ◆ Your name, company name, address, and phone number
- ◆ Lantronix product and model number
- ◆ Lantronix MAC address or serial number
- ◆ Firmware version and current configuration
- ◆ Description of the problem
- ◆ Status of the unit when the problem occurred (Please try to include information on user and network activity at the time of the problem).

B. Technical Specifications

Table B-1 XPress DR+ Specifications

Category	Description
CPU	Lantronix DSTNI-EX 48 MHz clock
Internal CPU Memory	256 KB SRAM
Flash	2 MB Flash
EEPROM	4 KB EEPROM
Serial Interface	2 RJ45 RS-232 Serial Ports Baud rate selectable from 300 to 230 Kbaud 1 Screw terminal RS-422/485 interface on Serial Port 2 (2 and 4 wire support) LED indicators for TXD and RXD activities
Serial Line Formats	Characters: 7 or 8 data bits Stop bits: 1 or 2 Parity: odd, even, none
Modem Control	DTR, DSR
Flow Control	Hardware: CTS/RTS Software: XON/XOFF
Reset (warm boot)	Front panel recessed push button. (This is not a reset to factory settings.)
Power Input	Removable screw terminal block connector 9-30 VDC or 9-24 VAC with chassis ground 2.3 Watts maximum
Network Interface	2 RJ45 10Base-T/100Base-TX Ethernet ports Embedded unmanaged fully compliant 802.3u non-blocking Ethernet switch Store and forward architecture with 1K MAC address lookup table Automatic MDI/MDI-X crossover Full duplex IEEE 802.3x flow control Half-duplex back pressure flow control
Dimensions	123 x 57 x 88 mm (4.85 x 2.25 x 3.45 in), terminal blocks included
Weight	0.21 kg (0.46 lb.)
Temperature	Operating range: -40°C to +70° C (-40 to 158 degrees F)
Humidity	20% to 90% relative humidity, non-condensing
Case	High-impact plastic case with integrated DIN-rail (35 mm) mount IP30 enclosure rating
Protocols Supported	ARP, UDP/IP, TCP/IP, Telnet, ICMP, SNMP, DHCP, BOOTP, TFTP, and HTTP
Installable Industrial Protocols	ModBus TCP, ModBus ASCII/RTU
Management	Internal web server (Standard Tunneling firmware only) SNMP (read only) Serial login Telnet login DeviceInstaller software
System Software	DeviceInstaller, Windows® based configuration software Com Port Redirector, Windows based virtual com port software

Category	Description
LEDs	TX/RX activity per serial Link/Activity per Ethernet port Power/System OK
Isolation	8 KV direct contact, 15 KV air discharge, ESD protection on all serial ports (IEC 1000-4-2, IEC 61000-4-2) 2 K VAC / 2.8K VDC galvanic isolation between power input port to Ethernet ports (except chassis ground) 2 K VAC / 2.8K VDC galvanic isolation between power input port to serial ports Transient Voltage protection and ESD with max non-repetitive surge current 800 A (8/20 us) (IEC 61000-4-2) 2 K VAC / 2.8K VDC galvanic isolation between Ethernet ports (except chassis ground) 2 K VAC / 2.8K VDC galvanic isolation between Ethernet ports to serial ports 40 A (5/50 ns) EFT protection (IEC 61000-4-4), 12 A (8/20 us) lightning protection (IEC 61000-4-5) on all Ethernet ports
Agency Approvals	UL, CSA, FCC, CE, TUV, CTick, VCCI

C. Lantronix Cables and Adapters

Table C-1 Lantronix Cables, Adapters, and Part Number

Lantronix P/N	Description	Applications
500-103-R	6' RJ45-to DB9F	Included with XPress DR+ for setup or device connectivity. Connects the RJ45 RS-232 serial ports of XPress DR+ to a DB9M DTE interface of a PC or serial device.
200.0062	Cable Ethernet CAT5; RJ45, 2 m (6.6 ft)	Connects the XPress DR+ Ethernet ports to an Ethernet switch/hub or is used for cascading from one XPress DR+ to another. Connects the XPress DR+ serial RJ45 RS-232 ports to a device using one of the adapters listed below.
200.0063	Cable Ethernet CAT5; RJ45, 5 m (16.4 ft)	Connects the XPress DR+ Ethernet ports to an Ethernet switch/hub or is used for cascading from one XPress DR+ to another. Connects the XPress DR+ serial RJ45 RS-232 ports to a device using one of the below listed adapters.
200.0064	Cable Ethernet CAT5; RJ45, 10 m (32.8 ft)	Connects the XPress DR+ Ethernet ports to an Ethernet switch/hub or is used for cascading from one XPress DR+ to another. Connects the XPress DR+ serial RJ45 RS-232 ports to a device using one of the adapters listed below.
200.0065	Cable Ethernet CAT5; RJ45, 15 m (49.2 ft)	Connects the XPress DR+ Ethernet ports to an Ethernet switch/hub or is used for cascading from one XPress DR+ to another. Connects the XPress DR+ serial RJ45 RS-232 ports to a device using one of the adapters listed below.
200.2066A	Adapter RJ45-to-DB25M	Allows a standard straight-pinned CAT5 cable to connect the XPress DR+ RJ45 serial ports to the DB25F DCE interface of a serial device.
200.2067A	Adapter RJ45-to-DB25F	Allows a standard straight-pinned CAT5 cable to connect the XPress DR+ RJ45 serial ports to the DB25M DTE interface of a serial device.
200.2069A	Adapter RJ45-to-DB9M	Allows a standard straight-pinned CAT5 cable to connect the XPress DR+ RJ45 serial ports to the DB9F DCE interface of a serial device.
200.2070A	Adapter RJ45-to-DB9F	Allows a standard straight-pinned CAT5 cable to connect the XPress DR+ to the DB9M DTE interface of a PC or serial device.

D. Alternative Methods of Assigning an IP Address

Earlier chapters describe how to assign a static IP address using DeviceInstaller, Web- Manager, and Setup Mode (through a Telnet or serial connection). This section covers other methods for assigning an IP address over the network.

DHCP

The unit ships with a default IP address of 0.0.0.0, which automatically enables DHCP. If a DHCP server exists on the network, it provides the unit with an IP address, gateway address, and subnet mask when the unit boots up.

You can use the DeviceInstaller software (if applicable) to search the network for the DHCP-assigned IP address and add it to the list of devices retrieved.

Note: This DHCP address does **not** appear in the unit's Setup Mode or in Web Manager. You can determine your unit's DHCP-assigned IP address in Monitor Mode. When you enter Monitor Mode from the serial port with network connection enabled and issue the **NC** (Network Communication) command, you see the unit's IP configuration.

AutoIP

The unit ships with a default IP address of 0.0.0.0, which automatically enables Auto IP within the unit. AutoIP is an alternative to DHCP that allows hosts to obtain an IP address automatically in smaller networks that may not have a DHCP server. A range of IP addresses (from 169.254.0.1 to 169.254.255.1) has been explicitly reserved for AutoIP-enabled devices. Do not use this range of Auto IP addresses over the Internet.

- ◆ If your unit cannot find a DHCP server, and you have not manually assigned an IP address to it, the unit automatically selects an address from the AutoIP reserved range. Then, your unit sends out a (ARP) request to other nodes on the same network to see whether the selected address is being used.
- ◆ If the selected address is not in use, the unit uses it for local subnet communication. □ □
- ◆ If another device is using the selected IP address, the unit selects another address from the AutoIP range and reboots. After reboot, the unit sends out another ARP request to see if the selected address is in use, and so on.

AutoIP does not replace DHCP. The unit continues to look for a DHCP server on the network. If it finds a DHCP server, the unit switches to the DHCP server-provided address and reboots.

Note: If a DHCP server is found, but it denies the request for an IP address, the unit does not attach to the network, but waits and retries.

You can disable AutoIP by setting the unit's IP address to **0.0.1.0**. This setting enables DHCP but disables AutoIP.

BOOTP

Similar to DHCP, but for smaller networks. Automatically assigns the IP address for a specific duration of time.

ARP and Telnet

If the unit has no IP address, you can use Address Resolution Protocol (ARP).

To assign a temporary IP address:

1. On a UNIX or Windows-based host, create an entry in the host's ARP table using the intended IP address and the hardware address of the unit (on the product label on the bottom of the unit).

```
arp -s 191.12.3.77 00:20:4a:xx:xx:xx
```

Note: For the ARP command to work on Windows 95, the ARP table on the PC must have at least one IP address defined other than its own.

2. If you are using Windows 95, type **ARP -A** at the DOS command prompt to verify that there is at least one entry in the ARP table. If the local machine is the only entry, ping another IP address on your network to build a new entry in the ARP table; the IP address must be a host other than the machine on which you are working. Once there is at least one additional entry in the ARP table, use the following command to ARP an IP address to the unit:

```
arp -s 191.12.3.77 00-20-4a-xx-xx-xx
```

3. Open a Telnet connection to port 1. The connection fails quickly, but the unit temporarily changes its IP address to the one designated in this step.

```
telnet 191.12.3.77 1
```

4. Open a Telnet connection to port 9999, and press **Enter** within **five seconds** to go into Setup Mode. If you wait longer than five seconds, the unit reboots.

```
telnet 191.12.3.77 9999
```

Note: The IP address you just set is temporary and reverts to the default value when the unit's power is reset, unless you configure the unit with a static IP address and store the changes permanently.

E. Binary to Hexadecimal Conversions

Many of the unit's configuration procedures require you to assemble a series of options (represented as bits) into a complete command (represented as a byte). The resulting binary value must be converted to a hexadecimal representation.

Converting Binary to Hexadecimal

Following are two simple ways to convert binary numbers to hexadecimal notation.

Conversion Table

Hexadecimal digits have values ranging from 0 to F, which are represented as 0-9, A (for 10), B (for 11), etc. To convert a binary value (for example, 0100 1100) to a hexadecimal representation, treat the upper and lower four bits separately to produce a two-digit hexadecimal number (in this case, 4C). Use the following table to convert values from binary to hexadecimal.


Table E-1 Conversion Table

Decimal	Binary	Hex	Decimal	Binary	Hex
0	0000	0	8	1000	8
1	0001	1	9	1001	9
2	0010	2	10	1010	A
3	0011	3	12	1100	C
4	0100	4	13	1101	D
5	0101	5	14	1110	E
6	0110	6	15	1111	F
7	0111	7			


Scientific Calculator

Another simple way to convert binary to hexadecimal is to use a scientific calculator, such as the one available on Windows' operating systems. For example:

1. On the Windows' Start menu, click **Programs→Accessories→Calculator**.
2. On the **View** menu, select **Scientific**. The scientific calculator displays.
3. Click **Bin** (Binary) and type the number you want to convert.



4. Click **Hex**. The hexadecimal value displays.



F. Compliance Information

Declaration of Conformity

(According to ISO/IEC Guide 22 and BS 7514)

Manufacturer's Name & Address:

Lantronix, 7535 Irvine Center Drive, Suite 100, Irvine, CA 92618 USA

Declares that the following product:

Product Name Model: XPress DR+ Industrial Device Server

Description: 2-Port Industrial Device Server

Conforms to the following standards or other normative documents:

Safety

UL 60950-1

CSA 22.2. No 60950-1-03

EN 60950-1

Table F-1 Electromagnetic Emissions and Immunity

ITE	
Emissions:	Immunity:
FCC Part 15 Subpart B Class A ICES-003 Issue 4 February 2004 Class A AS/NZS CISPR 22: 2004 Class A EN55022: 1998 + A1: 2000 + A2: 2003 CLASS A EN61000-3-2: 2000 Class A EN61000-3-3: 1995 +A1: 2001	EN55024: 1998 +A1: 2001 +A2: 2003 IEC_61000-4-2: 1995 IEC_61000-4-3: 1995 IEC_61000-4-4: 1995 IEC_61000-4-5: 1995 IEC_61000-4-6: 1996 IEC_61000-4-8: 1993 IEC_61000-4-11: 1994
Industrial Environment	
Emissions:	Immunity
FCC Part 18 Subpart C ICES-001 Issue 4 July 2004 EN61000-6-4: 2001 and AS/NZS 4251.2: 1999 CISPR11	EN61000-6-2: 2001 and AS/NZS 61000.6.2: 2002 IEC_61000-4-2: 1995 IEC_61000-4-3: 1995 IEC_61000-4-4: 1995 IEC_61000-4-5: 1995 IEC_61000-4-6: 1996 IEC_61000-4-8: 1993 IEC_61000-4-11: 1994

Radio

EN 300 328 v1.4.1 (2003-04), R&TTE Directive (1999/5/EC)

Australia/New Zealand AS/NZS 4771 (2000 + A1:2003)

Supplementary Information

This Class A digital apparatus complies with Canadian ICES-003 (CSA) and has been verified as being compliant within the Class A limits of the FCC Radio Frequency Device Rules (FCC Title 47, Part 15, Subpart B CLASS A), measured to CISPR 22: 1993 limits and methods of measurement of Radio Disturbance Characteristics of Information Technology Equipment. The product complies with the requirements of the Low Voltage Directive 72/23/EEC and the EMC Directive 89/336/EEC.

RoHS, REACH and WEEE Compliance Statement

Please visit <http://www.lantronix.com/legal/rohs/> for Lantronix's statement about RoHS, REACH and WEEE compliance.